

Brunswick County Public Utilities - NC

PO Box 249
Bolivia, NC 28422-0249

LELAND N.C.

Client Project# NORTHWEST WATER PLANT
Samples Received: 1/24/2025

Analytical Report 0125-825

PFAS by Isotope Dilution (non-potable water)

Report Issue Date: 3/6/2025

I certify that to the best of my knowledge all analytical data presented in this report have been checked for completeness, accuracy, errors and legibility in addition to having been conducted in accordance with approved protocol, and that all deviations and analytical problems are summarized in the appropriate narrative(s). This analytical report was prepared in Portable Document Format (.PDF) and contains 26 pages. This report shall not be reproduced except in full without approval of the laboratory. This will provide assurance that parts of the report are not taken out of context.

Amendment(s):

Signature:



Laura Boivin, QA Associate II



Enthalpy Analytical, LLC – Wilmington
Christina Kurnath, Project Manager
chkurnath@montrose-env.com / www.enthalpy.com
O: 910-876-6895
2714 Exchange Drive, Wilmington, NC 28405

Narrative Summary



Enthalpy Analytical Narrative Summary

Company	Brunswick County Public Utilities - NC
Job No.	0125-825-1
Client ID.	NORTHWEST WATER PLANT Site: LELAND N.C.

1. Custody

Catherine Messecar received the samples at 5.6 °C after being relinquished by Brunswick County Public Utilities - NC.

The samples were received in good condition. Prior to, during, and after analysis, the samples were kept under lock with access only to authorized personnel by Enthalpy Analytical, LLC.

Table 1 - Sample Inventory

EU Lab Sample ID	Client Sample ID	Matrix	Received
0125-825-001-1	012425-S01	aqueous	2025-01-24
0125-825-001-2	012425-S01	aqueous	2025-01-24
0125-825-002-1	012425-E01	aqueous	2025-01-24
0125-825-002-2	012425-E01	aqueous	2025-01-24

2. Methods and Analytes

A list of analytes of interest and corresponding methods of analysis is shown in Table 3. Abbreviations are defined in the listed Appendices.

Table 3 - Methods and Analytes

EU Method	Analytes	Cleanup Method
EU047	Brunswick List	ENVI-Carb

3. Analysis

The samples were analyzed using Sciex Triple Quad 7500 (LC/MS/MS "Bumblebee") and Waters Acquity UPLC equipped with Xevo TQ MS (LC/MS/MS "Pippin").

The samples were analyzed using more than one batch preparation and analytical sequence to report all analytes of interest.

4. Calibration

In the initial calibration, the reported analytes exhibited R^2 of = 0.99. The reported analytes in the calibration standards, Initial Calibration Verification (ICV) and continuing calibration (concal) met the accuracy criterion for native analytes.

Enthalpy Analytical Narrative Summary

Company	Brunswick County Public Utilities - NC
Job No.	0125-825-1
Client ID.	NORTHWEST WATER PLANT Site: LELAND N.C.

5. QC Notes

Ongoing Precision Recovery (OPR) control limits have not been established for some analytes of interest.

Analyte(s) were detected in the method blank (MB) at less than 1/2 LOQ that may also be less than LOD. No analyte(s) were detected in the sample(s) with less than 10 times the extract amount detected in MB and are reported with no adverse impact..

Except where noted below, the QC sample analyses passed all method criteria.

QC samples that did not meet method acceptance criteria were:

- MB_18869_PFAAS (d3-N-MeFOSA, d5-N-EtFOSA)
- OPR_18869_PFAAS (d3-N-MeFOSA, d5-N-EtFOSA)

See Reporting Notes below.

PFAS by Isotope Dilution (non-potable water) samples were extracted within 28 days, and extracts analyzed within 28 days.

6. Reporting Notes

The results presented in this report are representative of the samples as provided to the laboratory.

Some labeled extraction standards (ES) in the analyses recovered outside method control limits for ES recovery, as denoted by the "Q" qualifier. The target analytes are quantified based on their ratio to their labeled standard analogs. As a result, low or high labeled standard recovery do not cause any change to ratios or contribute any additional error in the measurement of the target analytes. When detected at a signal-to-noise above 10:1 the ES peak area is used to quantify its respective target analyte using accepted isotope dilution principles. The data is reported without adverse impact.

These analyses met the requirements of the TNI Standard. Any deviations from the requirements of the reference method or TNI Standard have been stated above.

Enthalpy Analytical, LLC in Wilmington NC is accredited by the Louisiana Department of Environmental Quality to the 2016 TNI Standard under certificate number 05075.



General Reporting Notes – Data Qualifiers

The following are general reporting notes that are applicable to all Enthalpy Analytical, LLC - Wilmington, NC data reports, unless specifically noted otherwise.

General Data Qualifiers

- Ac - Alternate calculation flag indicates the es recovery was calculated using the opening concal when either of the following situations is encountered in the data processing software: the ES recovery is over 400% or the JS is not detected.
- B – The analyte was found in the method blank, at a concentration that was at least 10% of the amount in the sample.
- Cxx – Two or more congeners co-elute. In EDDs, C denotes the lowest IUPAC congener in a co-elution group and additional co-eluters for the group ('xx') are shown with the number of the lowest IUPAC co-eluter.
- E – The reported concentration exceeds the calibration range (upper point of the calibration curve). For HRMS data, this condition does not imply additional measurement uncertainty. For LC-MS/MS data, these values should be considered as having measurement uncertainty higher than values within the calibration range.
- EDL – Estimated Detection Level: The EDL is unique to isotope dilution methods and reflects the conditions of analysis at the time of analysis, including the equipment used. Where the MDL is a static value, the EDL is a dynamic value.
- EMPC – Estimated Maximum Possible Concentration: EMPC is specific to Dioxin/Furan tests to indicate the determined ion-abundance ratio was outside the allowed theoretical range (usually due to being near the detection limit, although it can very rarely be caused by a co-eluting interference). The EMPC concentration is adjusted to reflect the value at the theoretical ion-abundance ratio.
- I/IR – The ion ratio between the primary and secondary ions was observed to be outside the method criteria. The analyte concentration may be inaccurate due to interference.
- J – The analyte has a concentration below the minimum calibration level (LOQ value) but greater than the LOD. These values should be considered as having measurement uncertainty higher than values within the calibration range
- L - For reports containing PFAS analytes only, this flag indicates that an analyte has a concentration below the Minimum Detection Limit (MDL) . The reported concentration is not recommended for regulatory use as the analyte signal may have a signal-to-noise ratio less than the criteria deemed necessary to be considered a detected analyte.
- LOD – Limit of Detection: For reports conforming to the DOD ELAP QSM, this is the QSM-defined LOD. For reports conforming to TNI requirements (but not DOD ELAP QSM requirements), this value is the minimum detection limit (MDL). The LOD is adjusted for sample weight or volume.

General Reporting Notes – Data Qualifiers

- LOQ – Limit of Quantitation: For reports conforming to the DOD ELAP QSM, this is the QSM-defined LOQ. For reports conforming to TNI requirements (but not DOD ELAP QSM requirements), this value is the reporting limit (RL). The LOQ is adjusted for sample weight or volume.
- <LOD() – Analyte was not found at a concentration high enough to be reported as detected. It is reported as less than the LOD, and the LOD is given in the parentheses.
- <LOQ() – Analyte was not found at a concentration high enough to be reported as above the QSM-defined LOQ or TNI defined Reporting Limit. It is reported as less than the LOQ, and the LOQ is given in the parentheses.
- ND – Indicates a non-detect.
- NR – Indicates a value that is not reportable due to issues observed in sample preparation or analysis.
- PR – The associated congener(s) is(are) poorly resolved.
- QI – Indicates the presence of a quantitative interference.
- RL – Reporting Limit. Lowest reportable value. The level is higher than the MDL.
- SI – Denotes “Single Ion Mode” and is utilized for PCBs where the secondary ion trace has a significantly elevated noise level due to background PFK. Responses for such peaks are calculated using an EMPC approach based solely on the primary ion area(s) and may be considered estimates.
- U – The analyte was not detected.
- V / Q – The labeled standard recovery is not within method control limits.
- X – Indicates the result is from re-injection/repeat/second-column analysis.

Lab Identifiers/ Data Attributes

- AR – Indicates use of the archived portion of the sample extract.
- CU – Indicates a sample that required additional clean-up prior to HRMS injection/processing.
- D – Dilution Data. Result was obtained from the analysis of a dilution. The number that follows the “D” indicates the dilution factor.
- DE – Indicates a dilution performed with the addition of ES (Extraction Standard) solution.
- DUP – Designation for a duplicate sample.
- MS – Designation for a matrix spike.
- MSD – Designation for a matrix spike duplicate.



General Reporting Notes – Data Qualifiers

- R – Indicates a re-extraction of the sample.
- RJ – Indicates a reinjection of the sample extract.
- S – Indicates a sample split. The number that follows the “S” indicates the split factor.
- SAT – Indicates an analyte saturated the detector.

PFAS Compound Acronym List			
Acronym	CAS #	Compound Name	
* accredited for SOP EU047 / EPA method 1633 # Method 537.1 Accredited ^ Method 533 Accredited ~EPA 1633 extended list			
Target Analytes			
* , ^	PFBA	375-22-4	Perfluorobutanoic Acid
* , # , ^	PFPeA	2706-90-3	Perfluoropentanoic Acid
* , # , ^	PFHxA	307-24-4	Perfluorohexanoic Acid
* , # , ^	PFHpA	375-85-9	Perfluoroheptanoic Acid
* , # , ^	PFOA	335-67-1	Perfluorooctanoic Acid
* , # , ^	PFNA	375-95-1	Perfluorononanoic Acid
* , # , ^	PFDA	335-76-2	Perfluorodecanoic acid
* , # , ^	PFUnA (PFUnDA)	2058-94-8	Perfluoroundecanoic acid
* , #	PFDoA (PFDoDA)	307-55-1	Perfluorododecanoic acid
* , #	PFTrDA (PFTriA)	72629-94-8	Perfluorotridecanoic acid
* , # , ^	PFTeDA (PFTA)	376-06-7	Perfluorotetradecanoic acid
* , ^	PFBS	375-73-5	Perfluorobutane sulfonic acid
* , # , ^	PFPeS	2706-91-4	Perfluoropentane sulfonic acid
* , ^	PFHxS	355-46-4	Perfluorohexane sulfonic acid
* , # , ^	PFHpS	375-92-8	Perfluoroheptane sulfonic acid
* , # , ^	PFOS	1763-23-1	Perfluorooctane sulfonic acid
*	PFNS	68259-12-1	Perfluorononane sulfonic acid
*	PFDS	335-77-3	Perfluorodecane sulfonic acid
* , ^	4:2 FTS	757124-72-4	4:2 fluorotelomer sulfonic acid
* , ^	6:2 FTS	27619-97-2	6:2 fluorotelomer sulfonic acid
* , ^	8:2 FTS	39108-34-4	8:2 fluorotelomer sulfonic acid
~	10:2 FTS	120226-60-0	Fluorotelomer sulfonate 10:2
~	FHxSA	41997-13-1	Perfluorohexanesulfonamide
*	PFOSA (FOSA)	754-91-6	Perfluorooctane sulfonamide
* , #	N-MeFOSAA	2355-31-9	N-methyl perfluorooctane sulfonamido acetic acid
*	N-MeFOSA	31506-32-8	N-methylperfluoro-1-octanesulfonamide
*	N-MeFOSE	24448-09-7	2-(N-methylperfluoro-1-octanesulfonamido)-ethanol
* , #	N-EtFOSAA	2991-50-6	N-ethyl perfluorooctane sulfonamido acetic acid
*	N-EtFOSA	4151-50-2	N-ethylperfluoro-1-octanesulfonamide
*	N-EtFOSE	1691-99-2	2-(N-methylperfluoro-1-octanesulfonamido)-ethanol
* , # , ^	HFPO-DA	13252-13-6	2,3,3,3-Tetrafluoro-2-(1,1,2,2,3,3,3-heptafluoropropoxy)-propanoic acid (Gen-X)
* , # , ^	11Cl-PF3OUdS	763051-92-9	11-chloroheptafluoro-3-oxadecane-1-sulfonic acid
* , # , ^	9Cl-PF3ONS	756426-58-1	9-chlorohexadecafluoro-3-oxanonane-1-sulfonic acid
* , # , ^	ADONA	919005-14-4	4,8-dioxa-3H-perfluorononanoic acid
* , ^	PFEESA	113507-82-7	Perfluoro(2-ethoxyethane)sulphonic acid
* , ^	PFMOBA (PFMBA)	863090-89-5	Perfluoro-4-methoxybutanoic acid
* , ^	NFDHA	151772-58-6	Nonafluoro-3,6-dioxahexanoic acid
* , ^	PFMOPrA (PFMPA)	377-73-1	Perfluoro-3-methoxypropanoic acid
~	PFPrA	422-64-0	2,2,3,3,3-Pentafluoropropionic acid
~	PFPrS (PFPS)	423-41-6	Perfluoropropanesulfonic acid
~	PFMOAA	674-13-5	Perfluoro-2-methoxyacetic acid
~	PFO2HxA	39492-88-1	Perfluoro (3,5-dioxahexanoic) acid
~	PFO3OA	39492-89-2	Perfluoro (3,5,7-trioxaoctanoic) acid
~	PFO4DA	39492-90-5	Perfluoro (3,5,7,9-tetraoxadecanoic) acid
~	PFO5DA	39492-91-6	Perfluoro(3,5,7,9,11-pentaoxadodecanoic) acid
~	Nafion Byproduct 1 (PS Acid)	29311-67-9	Nafion Byproduct 1
~	Nafion Byproduct 2 (Hydro-PS Acid)	749836-20-2	Nafion Byproduct 2
~	PEPA	267239-61-2	Perfluoro-2-ethoxypropanoic acid
~	PMPA	13140-29-9	Perfluoro-2-methoxypropanoic acid

PFAS Compound Acronym List		
Acronym	CAS #	Compound Name
* accredited for SOP EU047 / EPA method 1633	# Method 537.1 Accredited	^ Method 533 Accredited ~EPA 1633 extended list
~ PFECA-G	801212-59-9	4-(Heptafluoroisopropoxy)hexafluorobutanoic acid
~ PFHxDA	67905-19-5	Perfluorohexadecanoic acid
~ R-PSDA (Nafion Byproduct 4)	2416366-18-0	Perfluoro-4-(2-sulfoethoxy)pentanoic acid
Hydrolyzed PSDA (Nafion Byproduct 5)	2416366-19-1	2-fluoro-2-[1,1,2,3,3,3-hexafluoro-2-(1,1,2-tetrafluoro-2-sulfoethoxy)propoxy]-acetic acid
~ R-PSDCA (Nafion Byproduct 6)	2416366-21-5	1,1,2,2-tetrafluoro-2-[1,2,2,3,3-pentafluoro-1-(trifluoromethyl)propoxy] ethanesulfonic acid
~ EVE Acid	69087-46-3	2,2,3,3-tetrafluoro-3-({1,1,1,2,3,3-hexafluoro-3-[(1,2,2-trifluoroethenyl)oxy]propan-2-yl)oxy}propionic acid
~ FBSA	30334-69-1	Perfluorobutylsulfonamide
~ MeFBSA	68298-12-4	1-Butanesulfonamide; (N-(Methyl)nonafluorobutanesulfonamide)
~ Hydro-EVE Acid	773804-62-9	2,2,3,3-Tetrafluoro-3-[[1,1,1,2,3,3-hexafluoro-3-(1,2,2,2-tetrafluoroethoxy)propan-2-yl]oxy}propanoic acid
~ R-EVE Acid	2416366-22-6	4-(2-carboxy-1,1,2,2-tetrafluoroethoxy)-2,2,3,3,4,5,5,5-octafluoro-pentanoic acid
~ NVHOS	1132933-86-8	Perfluoroethoxysulfonic acid
*~ PFDoS	79780-39-5	Perfluorododecane sulfonic acid
~ PFODA	16517-11-6	Perfluorooctadecanoic acid
* 3:3 FTCA	356-02-5	2H,2H,3H,3H-Perfluorohexanoic acid
* 5:3 FTCA	914637-49-3	2H,2H,3H,3H-Perfluorooctanoic acid
* 7:3 FTCA	812-70-4	2H,2H,3H,3H-Perfluorodecanoic acid
~ N-AP-FHxSA	50598-28-2	N-(3-(Dimethylamino)propyl)tridecafluoro-1-hexanesulfonamide
~ N-CMAmP-6:2 FOSA	34455-29-3	N-(Carboxymethyl)-N,N-dimethyl-3-(((3,3,4,4,5,5,6,6,7,7,8,8,8-tridecafluorooctyl)sulfonyl)amino)1-propanaminium
~ BPAF	1478-61-1	Bisphenol AF
~ HQ-115	90076-65-6	Bis(trifluoromethane)sulfonimide lithium salt

Results

Enthalpy Analytical

Job No.: 0125-825-1 PFAS by Isotope Dilution (non-potable water)

Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Summary

	Compound	CAS	012425-S01 ng/L	012425-E01 ng/L
Acids	PFPrA	422-64-0	78.5 L	118 L
	PFBA	375-22-4	3.62	2.19
	PFPeA	2706-90-3	6.42	6.58
	PFHxA	307-24-4	5.38	5.40
	PFHpA	375-85-9	2.93	2.81
	PFOA	335-67-1	5.30	5.54
	PFNA	375-95-1	0.520 J	0.533 J
	PFDA	335-76-2	0.201 J	0.180 J
	PFUnDA	2058-94-8	ND U	ND U
	PFDoDA	307-55-1	ND U	ND U
	PFTrDA	72629-94-8	ND U	ND U
	PFTeDA	376-06-7	ND U	ND U
	PFHxDA	67905-19-5	ND U	ND U
	Sulfonates	PFBS	375-73-5	2.81
PFPeS		2706-91-4	0.444 J	0.614
PFHxS		355-46-4	3.85	3.62
PFHpS		375-92-8	0.118 L	0.115 L
PFOS		1763-23-1	8.91	8.76
PFNS		68259-12-1	ND U	ND U
PFDS		335-77-3	ND U	ND U
4:2 FTS		757124-72-4	ND U	ND U
6:2 FTS		27619-97-2	0.220 L	0.242 L
8:2 FTS		39108-34-4	ND U	ND U
10:2 FTS		120226-60-0	ND U	ND U
Sulfonamidos	FBSA	30334-69-1	0.279 J	0.309 J
	N-EFOSA	4151-50-2	ND U	ND U
	N-EFOSAA	2991-50-6	ND U	ND U
	N-EFOSE	1691-99-2	ND U	ND U
	N-MeFOSA	31506-32-8	ND U	ND U
	N-MeFOSAA	2355-31-9	ND U	ND U
	N-MeFOSE	24448-09-7	ND U	ND U
	PFOSA	754-91-6	ND U	ND U
	PFECAs	ADONA	919005-14-4	ND U
EVE Acid		69087-46-3	ND U	ND U
HFPO-DA		13252-13-6	3.53	3.59
Hydro-EVE Acid		773804-62-9	0.274 J	0.347 J
NFDHA		151772-58-6	ND U	ND U
PEPA		267239-61-2	1.99	1.75
PFECA-G		801212-59-9	ND U	ND U
PFMOAA		674-13-5	20.6	19.7
PFMOBA		863090-89-5	ND U	ND U
PFMOPrA		377-73-1	ND U	ND U
PFO2HxA		39492-88-1	3.11	3.09
PFO3OA		39492-89-2	0.796	0.683
PFO4DA		39492-90-5	ND U	ND U
PFO5DA		39492-91-6	ND U	ND U
PMPA		13140-29-9	5.89	5.21
R-EVE		2416366-22-6	8.36	13.0
PFESAs		11Cl-PF3OUds	763051-92-9	ND U
	9Cl-PF3ONS	756426-58-1	ND U	ND U
	Hydrolyzed PSDA	2416366-19-1	2.93	3.73
	Nafion Byproduct 1 (PS Acid)	29311-67-9	ND U	ND U
	Nafion Byproduct 2 (Hydro-PS Acid)	749836-20-2	0.149 L	0.236 L
	NVHOS	1132933-86-8	ND U	ND U
	PFEESA	113507-82-7	ND U	ND U
	R-PSDA	2416366-18-0	3.52	5.13
	R-PSDCA	2416366-21-5	ND U	ND U

Enthalpy Analytical

Job No.: 0125-825-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	012425-S01		
Sampling Site			
Enthalpy ID	0125-825-001-1	Prep Batch	EU18868
Matrix	aqueous	Analyst	ext-magennaef
Sampling Date	2025-01-24 11:55	Instrument	Bumblebee
Received Date	2025-01-24	Sample Vol mL	0.1
Prep Date	2025-01-29 08:10	Extract Vol mL	0.2
AnalysisDate	2025-02-03 20:33	Split Factor	N/A
SampleType	Sample	Method Code	EU-047-NPW
Bottle ID	A		

	Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFPrA	422-64-0	B030225-02032033	78.5	700	1530			L
ES	13C3-PFPrA		B030225-02032033				20-150%	87.5%	

Enthalpy Analytical

Job No.: 0125-825-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	012425-S01	Prep Batch	EU18869
Sampling Site		Analyst	jogres
Enthalpy ID	0125-825-001-2	Instrument	Pippin
Matrix	aqueous	Sample Vol mL	284.98
Sampling Date	2025-01-24 11:55	Extract Vol mL	0.4
Received Date	2025-01-24	Split Factor	N/A
Prep Date	2025-01-29 11:05	Method Code	EU-047-NPW
AnalysisDate	2025-01-30 14:01		
SampleType	Sample		
Bottle ID	A		

	Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags	
Acids	PFBA	375-22-4	P300125014	3.62	0.223	0.561				
	PFPeA	2706-90-3	P300125014	6.42	0.161	0.561				
	PFFhxA	307-24-4	P300125014	5.38	0.188	0.561				
	PFFHpA	375-85-9	P300125014	2.93	0.197	0.561				
	PFOA	335-67-1	P300125014	5.30	0.128	0.561				
	PFNA	375-95-1	P300125014	0.520	0.127	0.561			J	
	PFDA	335-76-2	P300125014	0.201	0.161	0.561			J	
	PFUnDA	2058-94-8	P300125014	ND	0.127	0.561			U	
	PFDoDA	307-55-1	P300125014	ND	0.228	0.561			U	
	PFTTrDA	72629-94-8	P300125014	ND	0.186	0.561			U	
	PFTeDA	376-06-7	P300125014	ND	0.214	0.561			U	
	PFFhxDA	67905-19-5	P300125014	ND	0.298	0.561			U	
	Sulfonates	PFBS	375-73-5	P300125014	2.81	0.298	0.561			
		PFFPeS	2706-91-4	P300125014	0.444	0.115	0.529			J
PFFhXS		355-46-4	P300125014	3.85	0.433	0.514				
PFFHpS		375-92-8	P300125014	0.118	0.272	0.535			L	
PFOS		1763-23-1	P300125014	8.91	0.297	0.520				
PFNS		68259-12-1	P300125014	ND	0.174	0.541			U	
PFDS		335-77-3	P300125014	ND	0.295	0.541			U	
4:2 FTS		757124-72-4	P300125014	ND	0.0728	0.526			U	
6:2 FTS		27619-97-2	P300125014	0.220	0.265	0.535			L	
8:2 FTS		39108-34-4	P300125014	ND	0.126	0.538			U	
10:2 FTS	120226-60-0	P300125014	ND	0.430	0.561			U		
Sulfonamidos	FBSA	30334-69-1	P300125014	0.279	0.267	0.561			J	
	N-EiFOSA	4151-50-2	P300125014	ND	0.347	0.561			U	
	N-EiFOSAA	2991-50-6	P300125014	ND	0.228	0.561			U	
	N-EiFOSE	1691-99-2	P300125014	ND	0.860	2.53			U	
	N-MeFOSA	31506-32-8	P300125014	ND	0.232	0.561			U	
	N-MeFOSAA	2355-31-9	P300125014	ND	0.158	0.561			U	
	N-MeFOSE	24448-09-7	P300125014	ND	0.533	2.53			U	
	PFOSA	754-91-6	P300125014	ND	0.0788	0.561			U	
	PFECAs	ADONA	919005-14-4	P300125014	ND	0.152	0.532			U
EVE Acid		69087-46-3	P300125014	ND	0.179	1.26			U	
HFPO-DA		13252-13-6	P300125014	3.53	0.0595	0.561				
Hydro-EVE Acid		773804-62-9	P300125014	0.274	0.184	0.561			J	
NFDHA		151772-58-6	P300125014	ND	0.118	0.561			U	
PEPA		267239-61-2	P300125014	1.99	0.105	0.561				
PFECA-G		801212-59-9	P300125014	ND	0.0749	0.561			U	
PFMOAA		674-13-5	P300125014	20.6	0.284	0.561				
PFMOBA		863090-89-5	P300125014	ND	0.942	1.26			U	
PFMOPrA		377-73-1	P300125014	ND	0.200	0.561			U	
PFO2HxA		39492-88-1	P300125014	3.11	0.181	0.561				
PFO3OA		39492-89-2	P300125014	0.796	0.258	0.561				
PFO4DA		39492-90-5	P300125014	ND	0.444	2.81			U	
PFO5DA		39492-91-6	P300125014	ND	0.449	2.81			U	
PMPA		13140-29-9	P300125014	5.89	0.132	0.561				
R-EVE		2416366-22-6	P300125014	8.36	0.932	1.26				
PFESAs		11Cl-PF3OUdS	763051-92-9	P300125014	ND	0.265	0.529			U
		9Cl-PF3ONS	756426-58-1	P300125014	ND	0.360	0.523			U
		Hydrolyzed PSDA	2416366-19-1	P300125014	2.93	0.374	0.561			
	Nafion Byproduct 1 (PS Acid)	29311-67-9	P300125014	ND	0.300	0.561			U	
	Nafion Byproduct 2 (Hydro-PS Acid)	749836-20-2	P300125014	0.149	0.465	0.561			L	
	NVHOS	1132933-86-8	P300125014	ND	0.0865	0.561			U	
	PFEESA	113507-82-7	P300125014	ND	0.169	0.561			U	
	R-PSDA	2416366-18-0	P300125014	3.52	2.47	2.47				
	R-PSDCA	2416366-21-5	P300125014	ND	0.237	0.561			U	
ES	MPFBA		P300125014				20-150%	83.1%		
	M5PFPeA		P300125014				20-150%	170%	Q	
	M3PFBS		P300125014				20-150%	230%	Q	
	M2-4:2 FTS		P300125014				20-150%	116%		
	M5PFFhxA		P300125014				20-150%	76.3%		
	M3HFPO-DA		P300125014				20-150%	59.2%		
	M4PFFHpA		P300125014				20-150%	87.4%		

Enthalpy Analytical

Job No.: 0125-825-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	012425-S01		
Sampling Site			
Enthalpy ID	0125-825-001-2	Prep Batch	EU18869
Matrix	aqueous	Analyst	jogres
Sampling Date	2025-01-24 11:55	Instrument	Pippin
Received Date	2025-01-24	Sample Vol mL	284.98
Prep Date	2025-01-29 11:05	Extract Vol mL	0.4
AnalysisDate	2025-01-30 14:01	Split Factor	N/A
SampleType	Sample	Method Code	EU-047-NPW
Bottle ID	A		

Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
M3PFHxS		P300125014				20-150%	87.6%	
M2-6:2 FTS		P300125014				20-150%	121%	
M8PFOA		P300125014				20-150%	85.2%	
M9PFNA		P300125014				20-150%	83.5%	
M8PFOS		P300125014				20-150%	80.4%	
M2-8:2 FTS		P300125014				20-150%	84.4%	
M8FOSA-I		P300125014				20-150%	68.6%	
M6PFDA		P300125014				20-150%	83.3%	
d3-N-MeFOSAA		P300125014				20-150%	74.4%	
d5-N-EtFOSAA		P300125014				20-150%	69.6%	
M7PFUdA		P300125014				20-150%	72.9%	
MPFDoA		P300125014				20-150%	48.2%	
M2PFTeDA		P300125014				20-150%	7.14%	Q
d3-N-MeFOSA		P300125014				10-200%	3.83%	Q
d5-N-EtFOSA		P300125014				10-200%	2.88%	Q
d7-N-MeFOSE		P300125014				10-200%	23.9%	
d9-N-EtFOSE		P300125014				10-200%	18.8%	

Enthalpy Analytical

Job No.: 0125-825-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	012425-E01		
Sampling Site			
Enthalpy ID	0125-825-002-1	Prep Batch	EU18868
Matrix	aqueous	Analyst	ext-magennaef
Sampling Date	2025-01-24 11:55	Instrument	Bumblebee
Received Date	2025-01-24	Sample Vol mL	0.1
Prep Date	2025-01-29 08:10	Extract Vol mL	0.2
AnalysisDate	2025-02-03 20:45	Split Factor	N/A
SampleType	Sample	Method Code	EU-047-NPW
Bottle ID	A		

	Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFPrA	422-64-0	8030225-02032045	118	700	1530			L
ES	13C3-PFPrA		8030225-02032045				20-150%	90.7%	

Enthalpy Analytical

Job No.: 0125-825-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	012425-E01	Prep Batch	EU18869
Sampling Site		Analyst	jogres
Enthalpy ID	0125-825-002-2	Instrument	Pippin
Matrix	aqueous	Sample Vol mL	281.6
Sampling Date	2025-01-24 11:55	Extract Vol mL	0.4
Received Date	2025-01-24	Split Factor	N/A
Prep Date	2025-01-29 11:05	Method Code	EU-047-NPW
AnalysisDate	2025-01-30 14:24		
SampleType	Sample		
Bottle ID	A		

	Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags	
Acids	PFBA	375-22-4	P300125015	2.19	0.225	0.568				
	PFPeA	2706-90-3	P300125015	6.58	0.162	0.568				
	PFFhxA	307-24-4	P300125015	5.40	0.190	0.568				
	PFFHpA	375-85-9	P300125015	2.81	0.199	0.568				
	PFOA	335-67-1	P300125015	5.54	0.130	0.568				
	PFNA	375-95-1	P300125015	0.533	0.128	0.568			J	
	PFDA	335-76-2	P300125015	0.180	0.162	0.568			J	
	PFUnDA	2058-94-8	P300125015	ND	0.128	0.568			U	
	PFFDoDA	307-55-1	P300125015	ND	0.231	0.568			U	
	PFTTrDA	72629-94-8	P300125015	ND	0.188	0.568			U	
	PFTeDA	376-06-7	P300125015	ND	0.217	0.568			U	
	PFFhxDA	67905-19-5	P300125015	ND	0.302	0.568			U	
	Sulfonates	PFBS	375-73-5	P300125015	2.99	0.302	0.568			
		PFFPeS	2706-91-4	P300125015	0.614	0.117	0.535			
PFFhXS		355-46-4	P300125015	3.62	0.439	0.520				
PFFHpS		375-92-8	P300125015	0.115	0.275	0.541			L	
PFOS		1763-23-1	P300125015	8.76	0.300	0.526				
PFNS		68259-12-1	P300125015	ND	0.176	0.547			U	
PFDS		335-77-3	P300125015	ND	0.298	0.547			U	
4:2 FTS		757124-72-4	P300125015	ND	0.0737	0.532			U	
6:2 FTS		27619-97-2	P300125015	0.242	0.268	0.541			L	
8:2 FTS		39108-34-4	P300125015	ND	0.127	0.544			U	
10:2 FTS	120226-60-0	P300125015	ND	0.435	0.568			U		
Sulfonamidos	FBSA	30334-69-1	P300125015	0.309	0.270	0.568			J	
	N-EiFOSA	4151-50-2	P300125015	ND	0.352	0.568			U	
	N-EiFOSAA	2991-50-6	P300125015	ND	0.231	0.568			U	
	N-EiFOSE	1691-99-2	P300125015	ND	0.870	2.56			U	
	N-MeFOSA	31506-32-8	P300125015	ND	0.234	0.568			U	
	N-MeFOSAA	2355-31-9	P300125015	ND	0.160	0.568			U	
	N-MeFOSE	24448-09-7	P300125015	ND	0.540	2.56			U	
	PFOSA	754-91-6	P300125015	ND	0.0797	0.568			U	
	PFECAs	ADONA	919005-14-4	P300125015	ND	0.154	0.538			U
EVE Acid		69087-46-3	P300125015	ND	0.181	1.28			U	
HFPO-DA		13252-13-6	P300125015	3.59	0.0602	0.568				
Hydro-EVE Acid		773804-62-9	P300125015	0.347	0.186	0.568			J	
NFDHA		151772-58-6	P300125015	ND	0.119	0.568			U	
PEPA		267239-61-2	P300125015	1.75	0.107	0.568				
PFECA-G		801212-59-9	P300125015	ND	0.0758	0.568			U	
PFMOAA		674-13-5	P300125015	19.7	0.288	0.568				
PFMOBA		863090-89-5	P300125015	ND	0.953	1.28			U	
PFMOPrA		377-73-1	P300125015	ND	0.202	0.568			U	
PFO2HxA		39492-88-1	P300125015	3.09	0.183	0.568				
PFO3OA		39492-89-2	P300125015	0.683	0.261	0.568				
PFO4DA		39492-90-5	P300125015	ND	0.449	2.84			U	
PFO5DA		39492-91-6	P300125015	ND	0.455	2.84			U	
PMPA		13140-29-9	P300125015	5.21	0.134	0.568				
R-EVE		2416366-22-6	P300125015	13.0	0.943	1.28				
PFESAs		11Cl-PF3OUdS	763051-92-9	P300125015	ND	0.268	0.535			U
	9Cl-PF3ONS	756426-58-1	P300125015	ND	0.364	0.529			U	
	Hydrolyzed PSDA	2416366-19-1	P300125015	3.73	0.378	0.568				
	Nafion Byproduct 1 (PS Acid)	29311-67-9	P300125015	ND	0.304	0.568			U	
	Nafion Byproduct 2 (Hydro-PS Acid)	749836-20-2	P300125015	0.236	0.471	0.568			L	
	NVHOS	1132933-86-8	P300125015	ND	0.0875	0.568			U	
	PFEESA	113507-82-7	P300125015	ND	0.171	0.568			U	
	R-PSDA	2416366-18-0	P300125015	5.13	2.50	2.50				
ES	R-PSDCA	2416366-21-5	P300125015	ND	0.240	0.568			U	
	MPFBA		P300125015				20-150%	84.4%		
	M5PFPeA		P300125015				20-150%	156%	Q	
	M3PFBS		P300125015				20-150%	202%	Q	
	M2-4:2 FTS		P300125015				20-150%	127%		
	M5PFFhxA		P300125015				20-150%	70.7%		
	M3HFPO-DA		P300125015				20-150%	52.4%		
M4PFFHpA		P300125015				20-150%	78.8%			

Enthalpy Analytical

Job No.: 0125-825-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	012425-E01		
Sampling Site			
Enthalpy ID	0125-825-002-2	Prep Batch	EU18869
Matrix	aqueous	Analyst	jogres
Sampling Date	2025-01-24 11:55	Instrument	Pippin
Received Date	2025-01-24	Sample Vol mL	281.6
Prep Date	2025-01-29 11:05	Extract Vol mL	0.4
AnalysisDate	2025-01-30 14:24	Split Factor	N/A
SampleType	Sample	Method Code	EU-047-NPW
Bottle ID	A		

Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
M3PFHxS		P300125015				20-150%	72.8%	
M2-6:2 FTS		P300125015				20-150%	112%	
M8PFOA		P300125015				20-150%	71.6%	
M9PFNA		P300125015				20-150%	65.0%	
M8PFOS		P300125015				20-150%	58.6%	
M2-8:2 FTS		P300125015				20-150%	65.2%	
M8FOSA-I		P300125015				20-150%	58.4%	
M6PFDA		P300125015				20-150%	57.6%	
d3-N-MeFOSAA		P300125015				20-150%	53.0%	
d5-N-EtFOSAA		P300125015				20-150%	52.2%	
M7PFUdA		P300125015				20-150%	53.9%	
MPFDoA		P300125015				20-150%	42.3%	
M2PFTeDA		P300125015				20-150%	13.4%	Q
d3-N-MeFOSA		P300125015				10-200%	9.35%	Q
d5-N-EtFOSA		P300125015				10-200%	9.91%	Q
d7-N-MeFOSE		P300125015				10-200%	31.2%	
d9-N-EtFOSE		P300125015				10-200%	30.9%	

QC Data

Enthalpy Analytical

Job No.: 0125-825-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	MB_18868_PFAS		
Sampling Site			
Enthalpy ID	MB_18868_PFAS	Prep Batch	EU18868
Matrix	aqueous	Analyst	ext-magennaef
Sampling Date		Instrument	Bumblebee
Received Date		Sample Vol mL	0.1
Prep Date	2025-01-29 08:10	Extract Vol mL	0.2
AnalysisDate	2025-02-03 20:10	Split Factor	N/A
SampleType	Blank	Method Code	EU-047-NPW
Bottle ID	-		

	Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFPrA	422-64-0	8030225-02032010	95.1	700	1530			L
ES	13C3-PFPrA		8030225-02032010				20-150%	89.0%	

Enthalpy Analytical

Job No.: 0125-825-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	MB_18869_PFAS	Prep Batch	EU18869
Sampling Site		Analyst	jogres
Enthalpy ID	MB_18869_PFAS	Instrument	Pippin
Matrix	aqueous	Sample Vol mL	250
Sampling Date		Extract Vol mL	0.4
Received Date		Split Factor	N/A
Prep Date	2025-01-29 11:05	Method Code	EU-047-NPW
AnalysisDate	2025-01-30 10:15		
SampleType	Blank		
Bottle ID	-		

	Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags	
Acids	PFBA	375-22-4	P300125004	ND	0.254	0.640			U	
	PFPeA	2706-90-3	P300125004	ND	0.183	0.640			U	
	PFFhxA	307-24-4	P300125004	ND	0.214	0.640			U	
	PFFHpA	375-85-9	P300125004	ND	0.224	0.640			U	
	PFOA	335-67-1	P300125004	ND	0.146	0.640			U	
	PFNA	375-95-1	P300125004	ND	0.145	0.640			U	
	PFDA	335-76-2	P300125004	ND	0.183	0.640			U	
	PFUnDA	2058-94-8	P300125004	ND	0.145	0.640			U	
	PFDODA	307-55-1	P300125004	ND	0.260	0.640			U	
	PFTTrDA	72629-94-8	P300125004	ND	0.212	0.640			U	
	PFTeDA	376-06-7	P300125004	ND	0.244	0.640			U	
	PFFhxDA	67905-19-5	P300125004	ND	0.340	0.640			U	
	Sulfonates	PFBS	375-73-5	P300125004	ND	0.340	0.640			U
		PFPeS	2706-91-4	P300125004	ND	0.131	0.603			U
PFFhXS		355-46-4	P300125004	ND	0.494	0.586			U	
PFFHpS		375-92-8	P300125004	ND	0.310	0.610			U	
PFOS		1763-23-1	P300125004	ND	0.338	0.593			U	
PFNS		68259-12-1	P300125004	ND	0.199	0.616			U	
PFDS		335-77-3	P300125004	ND	0.336	0.616			U	
4:2 FTS		757124-72-4	P300125004	ND	0.0830	0.600			U	
6:2 FTS		27619-97-2	P300125004	0.0218	0.302	0.610			L	
8:2 FTS		39108-34-4	P300125004	ND	0.143	0.613			U	
10:2 FTS	120226-60-0	P300125004	ND	0.490	0.640			U		
Sulfonamidos	FBSA	30334-69-1	P300125004	ND	0.304	0.640			U	
	N-EiFOSA	4151-50-2	P300125004	ND	0.396	0.640			U	
	N-EiFOSAA	2991-50-6	P300125004	ND	0.260	0.640			U	
	N-EiFOSE	1691-99-2	P300125004	ND	0.980	2.88			U	
	N-MeFOSA	31506-32-8	P300125004	ND	0.264	0.640			U	
	N-MeFOSAA	2355-31-9	P300125004	ND	0.180	0.640			U	
	N-MeFOSE	24448-09-7	P300125004	ND	0.608	2.88			U	
	PFOSA	754-91-6	P300125004	ND	0.0898	0.640			U	
PFECAs	ADONA	919005-14-4	P300125004	ND	0.173	0.606			U	
	EVE Acid	69087-46-3	P300125004	ND	0.204	1.44			U	
	HFPO-DA	13252-13-6	P300125004	ND	0.0678	0.640			U	
	Hydro-EVE Acid	773804-62-9	P300125004	ND	0.210	0.640			U	
	NFDHA	151772-58-6	P300125004	ND	0.135	0.640			U	
	PEPA	267239-61-2	P300125004	ND	0.120	0.640			U	
	PFECA-G	801212-59-9	P300125004	ND	0.0854	0.640			U	
	PFMOAA	674-13-5	P300125004	ND	0.324	0.640			U	
	PFMOBA	863090-89-5	P300125004	ND	1.07	1.44			U	
	PFMOPrA	377-73-1	P300125004	ND	0.228	0.640			U	
	PFO2HxA	39492-88-1	P300125004	ND	0.206	0.640			U	
	PFO3OA	39492-89-2	P300125004	ND	0.294	0.640			U	
	PFO4DA	39492-90-5	P300125004	ND	0.506	3.20			U	
	PFO5DA	39492-91-6	P300125004	ND	0.512	3.20			U	
	PMPA	13140-29-9	P300125004	ND	0.151	0.640			U	
	R-EVE	2416366-22-6	P300125004	ND	1.06	1.44			U	
	PFESAs	11Cl-PF3OUdS	763051-92-9	P300125004	ND	0.302	0.603			U
		9Cl-PF3ONS	756426-58-1	P300125004	ND	0.410	0.596			U
Hydrolyzed PSDA		2416366-19-1	P300125004	ND	0.426	0.640			U	
Nafion Byproduct 1 (PS Acid)		29311-67-9	P300125004	ND	0.342	0.640			U	
Nafion Byproduct 2 (Hydro-PS Acid)		749836-20-2	P300125004	ND	0.530	0.640			U	
NVHOS		1132933-86-8	P300125004	ND	0.0986	0.640			U	
PFEESA		113507-82-7	P300125004	ND	0.192	0.640			U	
R-PSDA		2416366-18-0	P300125004	ND	2.82	2.82			U	
R-PSDCA		2416366-21-5	P300125004	ND	0.270	0.640			U	
ES	MPFBA		P300125004				20-150%	84.9%		
	M5PFPeA		P300125004				20-150%	88.2%		
	M3PFBS		P300125004				20-150%	88.0%		
	M2-4:2 FTS		P300125004				20-150%	90.5%		
	M5PFFhxA		P300125004				20-150%	78.5%		
	M3HFPO-DA		P300125004				20-150%	57.6%		
	M4PFFHpA		P300125004				20-150%	90.9%		

Enthalpy Analytical

Job No.: 0125-825-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	MB_18869_PFAS		
Sampling Site			
Enthalpy ID	MB_18869_PFAS	Prep Batch	EU18869
Matrix	aqueous	Analyst	jogres
Sampling Date		Instrument	Pippin
Received Date		Sample Vol mL	250
Prep Date	2025-01-29 11:05	Extract Vol mL	0.4
AnalysisDate	2025-01-30 10:15	Split Factor	N/A
SampleType	Blank	Method Code	EU-047-NPW
Bottle ID	-		

Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
M3PFHxS		P300125004				20-150%	83.4%	
M2-6:2 FTS		P300125004				20-150%	109%	
M8PFOA		P300125004				20-150%	82.8%	
M9PFNA		P300125004				20-150%	79.4%	
M8PFOS		P300125004				20-150%	81.8%	
M2-8:2 FTS		P300125004				20-150%	125%	
M8FOSA-I		P300125004				20-150%	75.2%	
M6PFDA		P300125004				20-150%	83.1%	
d3-N-MeFOSAA		P300125004				20-150%	76.3%	
d5-N-EtFOSAA		P300125004				20-150%	74.1%	
M7PFUdA		P300125004				20-150%	88.7%	
MPFDoA		P300125004				20-150%	76.8%	
M2PFTeDA		P300125004				20-150%	47.1%	
d3-N-MeFOSA		P300125004				10-200%	7.96%	Q
d5-N-EtFOSA		P300125004				10-200%	7.69%	Q
d7-N-MeFOSE		P300125004				10-200%	41.5%	
d9-N-EtFOSE		P300125004				10-200%	41.8%	

Enthalpy Analytical

Job No.: 0125-825-1 PFAS by Isotope Dilution (non-potable water)

Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Enthalpy ID	OPR_18868_PFAS	Prep Batch	EU18868	Sample Vol (mL)	0.08
Sample Name	OPR_18868_PFAS	Prep Date	2025-01-29 08:10	Extract Vol (mL)	0.2
Matrix	aqueous	Analysis Date	2025-02-03 20:21	Split Factor	N/A
Sampling Date		Analyst	ext-magennaef	Method Code	EU-047-NPW
Received Date		Instrument	Bumblebee	Sample Type	Control
		Bottle ID	-		

	Compound	CAS	InjFileName	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFPrA	422-64-0	B030225-02032021	28900	875	1910	40-150%	116%	
ES	13C3-PFPrA		B030225-02032021				20-150%	87.0%	

Enthalpy Analytical

Job No.: 0125-825-1 PFAS by Isotope Dilution (non-potable water)

Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Enthalpy ID	OPR_18869_PFAS	Prep Batch	EU18869	Sample Vol (mL)	250
Sample Name	OPR_18869_PFAS	Prep Date	2025-01-29 11:05	Extract Vol (mL)	0.4
Matrix	aqueous	Analysis Date	2025-01-30 10:37	Split Factor	N/A
Sampling Date		Analyst	jogres	Method Code	EU-047-NPW
Received Date		Instrument	Pippin	Sample Type	Control
		Bottle ID	-		

	Compound	CAS	InjFileName	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags	
Acids	PFBA	375-22-4	P300125005	20.0	0.254	0.640	47.9-144%	99.8%		
	PFPeA	2706-90-3	P300125005	21.6	0.183	0.640	41.7-159%	108%		
	PFHxA	307-24-4	P300125005	20.1	0.214	0.640	43.2-154%	100%		
	PFHpA	375-85-9	P300125005	21.6	0.224	0.640	42.1-155%	108%		
	PFOA	335-67-1	P300125005	20.7	0.146	0.640	51.1-148%	104%		
	PFNA	375-95-1	P300125005	20.6	0.145	0.640	51.6-153%	103%		
	PFDA	335-76-2	P300125005	21.0	0.183	0.640	44.5-156%	105%		
	PFUnDA	2058-94-8	P300125005	20.9	0.145	0.640	40.3-156%	105%		
	PFDoDA	307-55-1	P300125005	21.0	0.260	0.640	40.4-158%	105%		
	PFTeDA	72629-94-8	P300125005	28.4	0.212	0.640	42.2-201%	142%		
	PFTeDA	376-06-7	P300125005	20.8	0.244	0.640	43-162%	104%		
	Sulfonates	PFBS	375-73-5	P300125005	18.5	0.340	0.640	42.7-155%	104%	
		PFPeS	2706-91-4	P300125005	20.2	0.131	0.603	40.3-152%	107%	
		PFHxS	355-46-4	P300125005	19.2	0.494	0.586	45-148%	105%	
PFHpS		375-92-8	P300125005	20.4	0.310	0.610	39.8-166%	107%		
PFOS		1763-23-1	P300125005	18.9	0.338	0.593	59.2-132%	102%		
PFNS		68259-12-1	P300125005	20.2	0.199	0.616	38.1-153%	105%		
PFDS		335-77-3	P300125005	18.4	0.336	0.616	28.6-148%	95.2%		
4:2 FTS		757124-72-4	P300125005	20.1	0.0830	0.600	41.5-157%	107%		
6:2 FTS		27619-97-2	P300125005	20.6	0.302	0.610	44.5-160%	108%		
8:2 FTS		39108-34-4	P300125005	21.6	0.143	0.613	39.4-166%	113%		
Sulfonamidos	N-EtFOSA	4151-50-2	P300125005	22.1	0.396	0.640	26.7-172%	111%		
	N-EtFOSAA	2991-50-6	P300125005	21.0	0.260	0.640	42.8-156%	105%		
	N-EtFOSE	1691-99-2	P300125005	94.3	0.980	2.88	38.9-161%	105%		
	N-MeFOSA	31506-32-8	P300125005	26.2	0.264	0.640	26.4-183%	131%		
	N-MeFOSAA	2355-31-9	P300125005	20.3	0.180	0.640	42-155%	102%		
	N-MeFOSE	24448-09-7	P300125005	96.7	0.608	2.88	37.6-155%	107%		
	PFOSA	754-91-6	P300125005	21.7	0.0898	0.640	39.1-158%	109%		
PFECAs	ADONA	919005-14-4	P300125005	19.4	0.173	0.606	32.2-151%	97.0%		
	HFPO-DA	13252-13-6	P300125005	23.8	0.0678	0.640	61.8-131%	119%		
PFESAs	11Cl-PF3OUdS	763051-92-9	P300125005	18.2	0.302	0.603	21.8-141%	90.8%		
	9Cl-PF3ONS	756426-58-1	P300125005	19.6	0.410	0.596	37.6-146%	97.8%		
ES	MPFBA		P300125005				20-150%	82.5%		
	M5PFPeA		P300125005				20-150%	86.7%		
	M3PFBS		P300125005				20-150%	84.7%		
	M2-4:2 FTS		P300125005				20-150%	87.2%		
	M5PFHxA		P300125005				20-150%	78.5%		
	M3HFPO-DA		P300125005				20-150%	60.8%		
	M4PFHpA		P300125005				20-150%	86.2%		
	M3PFHxS		P300125005				20-150%	80.7%		
	M2-6:2 FTS		P300125005				20-150%	109%		
	M8PFOA		P300125005				20-150%	85.0%		
	M9PFNA		P300125005				20-150%	78.9%		
	M8PFOS		P300125005				20-150%	78.0%		
	M2-8:2 FTS		P300125005				20-150%	97.5%		
	M8FOSA-I		P300125005				20-150%	68.8%		
	M6PFDA		P300125005				20-150%	82.0%		
	d3-N-MeFOSAA		P300125005				20-150%	73.1%		
	d5-N-EtFOSAA		P300125005				20-150%	70.8%		
	M7PFUdA		P300125005				20-150%	81.5%		
	MPFDoA		P300125005				20-150%	69.1%		
	M2PFTeDA		P300125005				20-150%	43.1%		
	d3-N-MeFOSA		P300125005				10-200%	1.88%	Q	
	d5-N-EtFOSA		P300125005				10-200%	1.94%	Q	
	d7-N-MeFOSE		P300125005				10-200%	38.3%		
d9-N-EtFOSE		P300125005				10-200%	38.4%			

Sample Custody



0125-825

Chain of Custody Record

Enthalpy Ultratrace Job#: _____ COC Page 1 of 1

Special Handling:

Standard Turn Around Time

Rush Turn Around Time -- Date Needed _____

• All Fast TATs Subject to Approval by Enthalpy Analytical, Inc.

• All Samples Disposed of After 6 months Unless Otherwise Instructed.

Enthalpy Analytical-Wilmington, NC has added enhancements to standard methods to improve accuracy, precision and permit an assessment of laboratory performance in the context of your specific data needs. For more information email Cindy.James@enthalpy.com

Client Name: BRUNSWICK COUNTY UTILITIES
 Project Manager: GLENN WALKER
 Report To: SAME

Project Number: _____
 Site Name: NORTHWEST WATER PLANT
 Location: LELAND N.C.

PO#: _____
 Telephone#: _____
 Email: _____

This Chain of Custody is applicable to Non-Air samples. Standard TAT differ per analysis and are provided by request.

Client Special Instructions:

Matrix: GW-Groundwater, WW-Wastewater, NW-Non-Potable Water, DW-Drinking Water, S-Soil, SL-Sludge, BT-Biological Tissue, O-Other

Type: G=Grab C=Composite Q=Quality Control

Sample ID	Date	Time	Sample Volume	Type	Matrix	Sample Containers				Analyses						Notes:				
						# of Bottles	# of Jars	# of Bags	# Other	Method 1613	Method 8290	Method 1668A/B/C/PCE	PFAS by LC/MS/MS	PAHs by HRGC/HRMS	Sample on Hold		Method 23	ALL PFAS		
012425-SO1	1/24/2025	1155AM	250 ml	G	NW	2												X	Please Add PFPrA and	
012425-EO1	1/24/2025	1155AM	250 ml	G	DW	2													X	PFHpA To The Testing.
																				Mark Hager Knows About
																				This If you Have Questions

Relinquished By:	Date:	Received By:	Date:	Time:	Sample Temperature Upon Receipt:
<u>BILLY BENTON</u>	<u>1/24/2025</u>	<u>Artie Messian</u>	<u>1/24/25</u>	<u>12:38</u>	<input checked="" type="checkbox"/> Iced <input type="checkbox"/> Ambient °C <u>5.6</u>
					<input type="checkbox"/> Iced <input type="checkbox"/> Ambient °C _____
					<input type="checkbox"/> Iced <input type="checkbox"/> Ambient °C _____

JOB ID: 0125-825

Date / Time: 1/24/25 11:38

Initials: C.P.M

OR

Client: Brunswick

Cooler 1 of 1

Temp °C: 5.6

Thermometer ID: T15

Received via

FedEx

UPS

DHL

USPS

Courier

Other

Check one

On ice:

Melted ice:

Ambient:

Check one

in a Box:

in a Cooler:

Cooler in Box:

Cooler seals:

Sample seals:

Good condition:

Yes

No

Comment:

Empty comment box

Cooler of

Temp °C:

Thermometer ID:

Received via

FedEx

UPS

DHL

USPS

Courier

Other

Check one

On ice:

Melted ice:

Ambient:

Check one

in a Box:

in a Cooler:

Cooler in Box:

Cooler seals:

Sample seals:

Good condition:

Yes

No

Comment:

Empty comment box

Cooler of

Temp °C:

Thermometer ID:

Received via

FedEx

UPS

DHL

USPS

Courier

Other

Check one

On ice:

Melted ice:

Ambient:

Check one

in a Box:

in a Cooler:

Cooler in Box:

Cooler seals:

Sample seals:

Good condition:

Yes

No

Comment:

Empty comment box