

Brunswick County Public Utilities - NC

PO Box 249
Bolivia, NC 28422-0249

LELAND N.C.

Client Project# NORTHWEST WATER PLANT
Samples Received: 7/7/2025

Analytical Report 0725-740

PFAS by Isotope Dilution (non-potable water)

Report Issue Date: 8/5/2025

I certify that to the best of my knowledge all analytical data presented in this report have been checked for completeness, accuracy, errors and legibility in addition to having been conducted in accordance with approved protocol, and that all deviations and analytical problems are summarized in the appropriate narrative(s). This analytical report was prepared in Portable Document Format (.PDF) and contains 32 pages. This report shall not be reproduced except in full without approval of the laboratory. This will provide assurance that parts of the report are not taken out of context.

Amendment(s):

Signature:



Laura Boivin, QA Associate II



Enthalpy Analytical, LLC – Wilmington
Christina Kurnath, Senior Project Manager
chkurnath@montrose-env.com / www.enthalpy.com
O: 910-876-6895
2714 Exchange Drive, Wilmington, NC 28405

Table of Contents

Case Narrative	3
General Reporting Notes	6
Results	12
Summary of Results	13
Detailed Results	14
QC Data	22
Blanks	23
Controls	27
Sample Custody	30
Chain of Custody	31

Narrative Summary

Enthalpy Analytical Narrative Summary

Company	Brunswick County Public Utilities - NC
Job No.	0725-740-1
Client ID.	NORTHWEST WATER PLANT Site: LELAND N.C.

1. Custody

Jayson-Shane Santos received the samples at 1.1 °C after being relinquished by Brunswick County Public Utilities - NC.

The samples were received in good condition. Prior to, during, and after analysis, the samples were kept under lock with access only to authorized personnel by Enthalpy Analytical, LLC.

Table 1 - Sample Inventory

EU Lab Sample ID	Client Sample ID	Matrix	Received
0725-740-001-1	070325-S01	aqueous	2025-07-07
0725-740-001-1A	070325-S01	aqueous	2025-07-07
0725-740-001-2	070325-S01	aqueous	2025-07-07
0725-740-002-1	070325-E01	aqueous	2025-07-07
0725-740-002-1A	070325-E01	aqueous	2025-07-07
0725-740-002-2	070325-E01	aqueous	2025-07-07

2. Methods and Analytes

A list of analytes of interest and corresponding methods of analysis is shown in Table 3. Abbreviations are defined in the listed Appendices.

Table 3 - Methods and Analytes

EU Method	Analytes	Cleanup Method
EU047	Brunswick List	ENVI-Carb

3. Analysis

The samples were analyzed using LC/MS/MS instruments Bumblebee and Pippin.

The samples were analyzed using more than one batch preparation and analytical sequence to meet method acceptance criteria.

Polar compound PFPrA in the samples, including the method blank (MB) and Ongoing Precision Recovery (OPR) samples, was analyzed by direct inject calibration.

4. Calibration

In the initial calibration, the reported analytes exhibited R^2 of ≥ 0.99 . The reported analytes in the calibration standards, Initial Calibration Verification (ICV) and continuing calibration (concal) met the accuracy criterion for native analytes.

Enthalpy Analytical Narrative Summary

Company	Brunswick County Public Utilities - NC
Job No.	0725-740-1
Client ID.	NORTHWEST WATER PLANT Site: LELAND N.C.

The Standards that did not were:

- POLAR CS4 SID BG19 (13C3-PFPrA)
- POLAR CS5 SID BG18 (13C3-PFPrA)

Select extraction standards (ES) deviated from method control limits in the concal(s). Where recovery met signal-to-noise threshold and impacted analyte(s) met method recovery criteria, the data is accepted with no adverse impact.

5. QC Notes

Ongoing Precision Recovery (OPR) control limits have not been established for some analytes of interest.

Except where noted below, the QC sample analyses passed all method criteria.

QC samples that did not meet method acceptance criteria were:

- MB_118352_PFAS (13C3-PFPrA)
- OPR_118352_PFAS (13C3-PFPrA)
- OPR_118420_PFAS (d3-N-MeFOSA, d5-N-EtFOSA)

See additional Reporting Notes below.

PFAS by Isotope Dilution (non-potable water) samples were extracted within 28 days, and extracts analyzed within 28 days.

6. Reporting Notes

The results presented in this report are representative of the samples as provided to the laboratory.

This report provides all results including detections below LOD following client instruction.

Some labeled extraction standards (ES) in the analyses recovered outside method control limits for ES recovery, as denoted by the "Q" qualifier. The target analytes are quantified based on their ratio to their labeled standard analogs. As a result, low or high labeled standard recovery do not cause any change to ratios or contribute any additional error in the measurement of the target analytes. When detected at a signal-to-noise above 10:1 the ES peak area is used to quantify its respective target analyte using accepted isotope dilution principles. The data is reported without adverse impact.

These analyses met the requirements of the TNI Standard. Any deviations from the requirements of the reference method or TNI Standard have been stated above.

Enthalpy Analytical, LLC in Wilmington NC is accredited by the Louisiana Department of Environmental Quality to the 2016 TNI Standard under certificate number 05075.

General Reporting Notes – Data Qualifiers

The following are general reporting notes that are applicable to all Enthalpy Analytical, LLC - Wilmington, NC data reports, unless specifically noted otherwise.

General Data Qualifiers

- Ac - Alternate calculation flag indicates the es recovery was calculated using the opening concal when either of the following situations is encountered in the data processing software: the ES recovery is over 400% or the JS is not detected.
- B – The analyte was found in the method blank, at a concentration that was at least 10% of the amount in the sample.
- Cxx – Two or more congeners co-elute. In EDDs, C denotes the lowest IUPAC congener in a co-elution group and additional co-eluters for the group ('xx') are shown with the number of the lowest IUPAC co-eluter.
- E – The reported concentration exceeds the calibration range (upper point of the calibration curve). For HRMS data, this condition does not imply additional measurement uncertainty. For LC-MS/MS data, these values should be considered as having measurement uncertainty higher than values within the calibration range.
- EDL – Estimated Detection Level: The EDL is unique to isotope dilution methods and reflects the conditions of analysis at the time of analysis, including the equipment used. Where the MDL is a static value, the EDL is a dynamic value.
- EMPC – Estimated Maximum Possible Concentration: EMPC is specific to Dioxin/Furan tests to indicate the determined ion-abundance ratio was outside the allowed theoretical range (usually due to being near the detection limit, although it can very rarely be caused by a co-eluting interference). The EMPC concentration is adjusted to reflect the value at the theoretical ion-abundance ratio.
- I/IR – The ion ratio between the primary and secondary ions was observed to be outside the method criteria. The analyte concentration may be inaccurate due to interference.
- J – The analyte has a concentration below the minimum calibration level (LOQ value) but greater than the LOD. These values should be considered as having measurement uncertainty higher than values within the calibration range
- L - For reports containing PFAS analytes only, this flag indicates that an analyte has a concentration below the Minimum Detection Limit (MDL) . The reported concentration is not recommended for regulatory use as the analyte signal may have a signal-to-noise ratio less than the criteria deemed necessary to be considered a detected analyte.
- LOD – Limit of Detection: For reports conforming to the DOD ELAP QSM, this is the QSM-defined LOD. For reports conforming to TNI requirements (but not DOD ELAP QSM requirements), this value is the minimum detection limit (MDL). The LOD is adjusted for sample weight or volume.

General Reporting Notes – Data Qualifiers

- LOQ – Limit of Quantitation: For reports conforming to the DOD ELAP QSM, this is the QSM-defined LOQ. For reports conforming to TNI requirements (but not DOD ELAP QSM requirements), this value is the reporting limit (RL). The LOQ is adjusted for sample weight or volume.
- <LOD() – Analyte was not found at a concentration high enough to be reported as detected. It is reported as less than the LOD, and the LOD is given in the parentheses.
- <LOQ() – Analyte was not found at a concentration high enough to be reported as above the QSM-defined LOQ or TNI defined Reporting Limit. It is reported as less than the LOQ, and the LOQ is given in the parentheses.
- ND – Indicates a non-detect.
- NR – Indicates a value that is not reportable due to issues observed in sample preparation or analysis.
- PR – The associated congener(s) is(are) poorly resolved.
- QI – Indicates the presence of a quantitative interference.
- RL – Reporting Limit. Lowest reportable value. The level is higher than the MDL.
- SI – Denotes “Single Ion Mode” and is utilized for PCBs where the secondary ion trace has a significantly elevated noise level due to background PFK. Responses for such peaks are calculated using an EMPC approach based solely on the primary ion area(s) and may be considered estimates.
- U – The analyte was not detected.
- V / Q – The labeled standard recovery is not within method control limits.
- X – Indicates the result is from re-injection/repeat/second-column analysis.

Lab Identifiers/ Data Attributes

- AR – Indicates use of the archived portion of the sample extract.
- CU – Indicates a sample that required additional clean-up prior to HRMS injection/processing.
- D – Dilution Data. Result was obtained from the analysis of a dilution. The number that follows the “D” indicates the dilution factor.
- DE – Indicates a dilution performed with the addition of ES (Extraction Standard) solution.
- DUP – Designation for a duplicate sample.
- MS – Designation for a matrix spike.
- MSD – Designation for a matrix spike duplicate.



General Reporting Notes – Data Qualifiers

- R – Indicates a re-extraction of the sample.
- RJ – Indicates a reinjection of the sample extract.
- S – Indicates a sample split. The number that follows the “S” indicates the split factor.
- SAT – Indicates an analyte saturated the detector.

PFAS Compound Acronym List			Methods					
Acronym	CAS #	Compound Name	SOP EU047	EPA 1633 (B-24)	EPA 1633X	EPA 537.1	EPA 533	EPA 8327*
Target Analytes								
PFBA	375-22-4	Perfluorobutanoic Acid	X	X	X		X	X
PFPeA	2706-90-3	Perfluoropentanoic Acid	X	X	X		X	X
PFHxA	307-24-4	Perfluorohexanoic Acid	X	X	X	X	X	X
PFHpA	375-85-9	Perfluoroheptanoic Acid	X	X	X	X	X	X
PFOA	335-67-1	Perfluorooctanoic Acid	X	X	X	X	X	X
PFNA	375-95-1	Perfluorononanoic Acid	X	X	X	X	X	X
PFDA	335-76-2	Perfluorodecanoic acid	X	X	X	X	X	X
PFUnA (PFUnDA)	2058-94-8	Perfluoroundecanoic acid	X	X	X	X	X	X
PFDoA (PFDoDA)	307-55-1	Perfluorododecanoic acid	X	X	X	X		X
PFTrDA (PFTriA, PFTrDA)	72629-94-8	Perfluorotridecanoic acid	X	X	X	X		X
PFTeDA (PFTA, PFTreA)	376-06-7	Perfluorotetradecanoic acid	X	X	X	X		X
PFBS	375-73-5	Perfluorobutane sulfonic acid	X	X	X	X	X	X
PFPeS	2706-91-4	Perfluoropentane sulfonic acid	X	X	X		X	X
PFHxS	355-46-4	Perfluorohexane sulfonic acid	X	X	X	X	X	X
PFHpS	375-92-8	Perfluoroheptane sulfonic acid	X	X	X		X	X
PFOS	1763-23-1	Perfluorooctane sulfonic acid	X	X	X	X	X	X
PFNS	68259-12-1	Perfluorononane sulfonic acid	X	X	X			X
PFDS	335-77-3	Perfluorodecane sulfonic acid	X	X	X			X
4:2 FTS	757124-72-4	4:2 fluorotelomer sulfonic acid	X	X	X		X	X
6:2 FTS	27619-97-2	6:2 fluorotelomer sulfonic acid	X	X	X		X	X
8:2 FTS	39108-34-4	8:2 fluorotelomer sulfonic acid	X	X	X		X	X
10:2 FTS	120226-60-0	Fluorotelomer sulfonate 10:2						X
FHxSA	41997-13-1	Perfluorohexanesulfonamide			X			X
PFOSA (FOSA)	754-91-6	Perfluorooctane sulfonamide	X	X	X			X
N-MeFOSAA	2355-31-9	N-methyl perfluorooctane sulfonamido acetic acid	X	X	X	X		X
N-MeFOSA	31506-32-8	N-methylperfluoro-1-octanesulfonamide	X	X	X			X
N-MeFOSE	24448-09-7	2-(N-methylperfluoro-1-octanesulfonamido)-ethanol	X	X	X			X
N-EtFOSAA	2991-50-6	N-ethyl perfluorooctane sulfonamido acetic acid	X	X	X	X		X
N-EtFOSA	4151-50-2	N-ethylperfluoro-1-octanesulfonamide	X	X	X			X
N-EtFOSE	1691-99-2	2-(N-Ethylperfluoro-1-octanesulfonamido)-ethanol	X	X	X			X
HFPO-DA	13252-13-6	Hexafluoropropyleneoxide dimer acid (GenX)	X	X	X	X	X	X
11Cl-PF3OUds	763051-92-9	11-chloroeicosafluoro-3-oxaundecane-1-sulfonic acid	X	X	X	X	X	X
9Cl-PF3ONS	756426-58-1	9-chlorohexadecafluoro-3-oxanonane-1-sulfonic acid	X	X	X	X	X	X
ADONA	919005-14-4	4,8-dioxa-3H-perfluorononanoic acid	X	X	X	X	X	X
PFESA	113507-82-7	Perfluoro(2-ethoxyethane)sulfonic acid		X	X		X	X
PFMOBA (PFMBA)	863090-89-5	Perfluoro-4-methoxybutanoic acid		X	X		X	X
NFDHA	151772-58-6	Nonafluoro-3,6-dioxaheptanoic acid		X	X		X	X
PFMOPrA (PFMPA)	377-73-1	Perfluoro-3-methoxypropanoic acid		X	X		X	X
PFPrA	422-64-0	Perfluoropropionic acid, 2,2,3,3,3-Pentafluoropropionic acid			X			X
PFPrS (PFPS)	423-41-6	Perfluoropropanesulfonic acid			X			X



PFAS Compound Acronym List			Methods					
Acronym	CAS #	Compound Name	SOP EU047	EPA 1633 (B-24)	EPA 1633X	EPA 537.1	EPA 533	EPA 8327*
PFMOAA	674-13-5	Perfluoro-2-methoxyacetic acid;			X			X
PFO2HxA	39492-88-1	Perfluoro (3,5-dioxahexanoic) acid			X			X
PFO3OA	39492-89-2	Perfluoro (3,5,7-trioxaoctanoic) acid			X			X
PFO4DA	39492-90-5	Perfluoro (3,5,7,9-tetraoxadecanoic) acid			X			X
PFO5DA	39492-91-6	Perfluoro(3,5,7,9,11-pentaoxadodecanoic) acid			X			X
Nafion Byproduct 1 (PS Acid)	29311-67-9	1,1,2,2-tetrafluoro-2-[1,1,1,2,3,3-hexafluoro-3-(1,2,2-trifluoroethenoxy)propan-2-yl]oxyethanesulfonic acid			X			X
Nafion Byproduct 2 (Hydro-PS Acid)	749836-20-2	Perfluoro-2-[[perfluoro-3-(perfluoroethoxy)-2-propanyl]oxy]ethanesulfonic acid (Hydro-PS Acid)			X			X
PEPA	267239-61-2	Perfluoro-2-ethoxypropanoic acid			X			X
PMPA	13140-29-9	Perfluoro-2-methoxypropanoic acid			X			X
PFECA-G, (PFPE-1)	801212-59-9	4-(Heptafluoroisopropoxy)hexafluorobutanoic acid, Perfluoro-4-isopropoxybutanoic acid			X			X
PFHxDA	67905-19-5	Perfluorohexadecanoic acid			X			X
R-PSDA (Nafion Byproduct 4)	2416366-18-0	Perfluoro-4-(2-sulfoethoxy)pentanoic acid; 2,2,3,3,4,5,5-Octafluoro-4-(1,1,2,2-tetrafluoro-2-sulfoethoxy)pentanoic acid			X			X
Hydrolyzed PSDA (Nafion Byproduct 5)	2416366-19-1	2-fluoro-2-[1,1,2,3,3,3-hexafluoro-2-(1,1,2,2-tetrafluoro-2-sulfoethoxy)propoxy]-acetic acid			X			X
R-PSDCA (Nafion Byproduct 6)	2416366-21-5	1,1,2,2-tetrafluoro-2-[1,2,2,3,3-pentafluoro-1-(trifluoromethyl)propoxy] ethanesulfonic acid			X			X
EVE Acid	69087-46-3	2,2,3,3-tetrafluoro-3-((1,1,1,2,3,3-hexafluoro-3-[(1,2,2-trifluoroethenyl)oxy]propan-2-yl)oxy)propionic acid			X			X
FBSA	30334-69-1	Perfluorobutylsulfonamide			X			X
MeFBSA	68298-12-4	1-Butanesulfonamide; (N-(Methyl)nonafluorobutanesulfonamide); 1,1,2,2,3,3,4,4,4-nonafluoro-N-methyl-1-Butanesulfonamide			X			X
Hydro-EVE Acid	773804-62-9	2,2,3,3-Tetrafluoro-3-[[1,1,1,2,3,3-hexafluoro-3-(1,2,2,2-tetrafluoroethoxy)propan-2-yl]oxy}propanoic acid			X			X
R-EVE Acid	2416366-22-6	4-(2-carboxy-1,1,2,2-tetrafluoroethoxy)-2,2,3,3,4,5,5,5-octafluoro-pentanoic acid			X			X
NVHOS	1132933-86-8	Perfluoroethoxysulfonic acid; 1,1,2,2-Tetrafluoro-2-(1,2,2,2-tetrafluoroethoxy)ethane-1-sulfonic acid			X			X

PFAS Compound Acronym List			Methods					
Acronym	CAS #	Compound Name	SOP EU047	EPA 1633 (B-24)	EPA 1633X	EPA 537.1	EPA 533	EPA 8327*
PFDoS	79780-39-5	Perfluorododecane sulfonic acid		X	X			X
PFOA	16517-11-6	Perfluorooctadecanoic acid			X			
3:3 FTCA	356-02-5	2H,2H,3H,3H-Perfluorohexanoic acid		X	X			X
5:3 FTCA	914637-49-3	2H,2H,3H,3H-Perfluorooctanoic acid		X	X			X
7:3 FTCA	812-70-4	2H,2H,3H,3H-Perfluorodecanoic acid		X	X			X
N-AP-FHxSA	50598-28-2	N-(3-(Dimethylamino)propyl)tridecafluoro-1-hexanesulfonamide			X			X
N-CMAmP-6:2 FOSA	34455-29-3	N-(Carboxymethyl)-N,N-dimethyl-3-(((3,3,4,4,5,5,6,6,7,7,8,8,8-tridecafluorooctyl)sulfonyl)amino)1-propanaminium			X			X
BPAF	1478-61-1	Bisphenol AF			X			X
HQ-115	90076-65-6	Bis(trifluoromethane)sulfonimide lithium salt			X			X

* Accreditation pending

Results

Enthalpy Analytical

Job No.: 0725-740-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Summary

	Compound	CAS	070325-S01 ng/L	070325-S01 ng/L	070325-E01 ng/L	070325-E01 ng/L	
Acids	PFPtA	422-64-0	ND U		ND U		
	PFBA	375-22-4	5.42		9.21		
	PFPeA	2706-90-3	6.67		9.82		
	PFHxA	307-24-4	6.72		89.4		
	PFHpA	375-85-9	2.83		5.85		
	PFOA	335-67-1	5.01		7.08		
	PFNA	375-95-1	0.814		1.09		
	PFDA	335-76-2	0.451 J		0.510 J		
	PFUnDA	2058-94-8	0.0303 L		0.0122 L		
	PFDoDA	307-55-1	ND U		ND U		
	PFTtDA	72629-94-8	ND U		ND U		
	PFTeDA	376-06-7	ND U		ND U		
	PFHxDA	67905-19-5	ND U		ND U		
	Sulfonates	PFBS	375-73-5	2.86		3.31	
		PFPeS	2706-91-4	0.547 J		ND U	
PFHxS		355-46-4	3.92		4.87		
PFHpS		375-92-8	0.150 L		0.176 L		
PFOS		1763-23-1	10.3		20.0		
PFNS		68259-12-1	ND U		ND U		
PFDS		335-77-3	ND U		ND U		
4:2 FTS		757124-72-4	ND U		3.72		
6:2 FTS		27619-97-2		0.0432 L		0.0837 L	
8:2 FTS		39108-34-4	0.0175 L		0.818		
10:2 FTS	120226-60-0	ND U		0.125 L			
Sulfonamidos	FBSA	30334-69-1	0.449 J		0.379 J		
	N-EtFOSA	4151-50-2	ND U		ND U		
	N-EtFOSAA	2991-50-6	ND U		ND U		
	N-EtFOSE	1691-99-2	ND U		ND U		
	N-MeFOSA	31506-32-8	ND U		ND U		
	N-MeFOSAA	2355-31-9	ND U		ND U		
	N-MeFOSE	24448-09-7	ND U		ND U		
	PFOSA	754-91-6	ND U		ND U		
PFECAs	ADONA	919005-14-4	ND U		ND U		
	EVE Acid	69087-46-3	0.0000823 L		0.00112 L		
	HFPO-DA	13252-13-6	4.73		5.95		
	Hydro-EVE Acid	773804-62-9	0.107 L		0.492 J		
	NFDHA	151772-58-6	ND U		ND U		
	PEPA	267239-61-2	3.83		3.99		
	PFECA-G	801212-59-9	ND U		ND U		
	PFMOAA	674-13-5	17.3		10.0		
	PFMOBA	863090-89-5	ND U		ND U		
	PFMOPrA	377-73-1	ND U		ND U		
	PFO2HxA	39492-88-1	3.58		3.14		
	PFO3OA	39492-89-2	0.918		0.940		
	PFO4DA	39492-90-5	ND U		ND U		
	PFO5DA	39492-91-6	ND U		ND U		
	PMPA	13140-29-9	6.63		8.58		
	R-EVE	2416366-22-6	3.33		11.7		
	PFESAs	11Cl-PF3OUdS	763051-92-9	ND U		ND U	
		9Cl-PF3ONS	756426-58-1	ND U		ND U	
Hydrolyzed PSDA		2416366-19-1	2.06		9.24		
Nafion Byproduct 1 (PS Acid)		29311-67-9	ND U		ND U		
Nafion Byproduct 2 (Hydro-PS Acid)		749836-20-2	0.273 L		0.603 L		
NVHOS		1132933-86-8	0.254 J		1.15		
PFEESA		113507-82-7	ND U		ND U		
R-PSDA		2416366-18-0	2.94		11.1		
R-PSDCA		2416366-21-5	ND U		0.0288 L		

Enthalpy Analytical

Job No.: 0725-740-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	070325-S01		
Sampling Site			
Enthalpy ID	0725-740-001-1	Prep Batch	EU118352
Matrix	aqueous	Analyst	jogres
Sampling Date	2025-07-03 10:30	Instrument	Bumblebee
Received Date	2025-07-07	Sample Vol mL	0.1
Prep Date	2025-07-10 16:14	Extract Vol mL	0.2
AnalysisDate	2025-07-10 18:24	Split Factor	N/A
SampleType	Sample	Method Code	EU-047-NPW
Bottle ID	A		

	Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFPrA	422-64-0	8100725-07101824	ND	700	1530			U
ES	13C3-PFPrA		8100725-07101824				20-150%	229%	Q

Enthalpy Analytical

Job No.: 0725-740-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	070325-S01	Prep Batch	EU118420
Sampling Site		Analyst	ext-magennaef
Enthalpy ID	0725-740-001-1A	Instrument	Pippin
Matrix	aqueous	Sample Vol mL	253.07
Sampling Date	2025-07-03 10:30	Extract Vol mL	0.4
Received Date	2025-07-07	Split Factor	N/A
Prep Date	2025-07-18 09:00	Method Code	EU-047-NPW
AnalysisDate	2025-07-24 20:32		
SampleType	Sample		
Bottle ID	A		

	Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags	
Acids	PFBA	375-22-4	P240725018	5.42	0.251	0.632				
	PFPeA	2706-90-3	P240725018	6.67	0.181	0.632				
	PFHxA	307-24-4	P240725018	6.72	0.211	0.632				
	PFHpA	375-85-9	P240725018	2.83	0.221	0.632				
	PFOA	335-67-1	P240725018	5.01	0.145	0.632				
	PFNA	375-95-1	P240725018	0.814	0.143	0.632				
	PFDA	335-76-2	P240725018	0.451	0.181	0.632			J	
	PFUnDA	2058-94-8	P240725018	0.0303	0.143	0.632			L	
	PFDoDA	307-55-1	P240725018	ND	0.257	0.632			U	
	PFTrDA	72629-94-8	P240725018	ND	0.209	0.632			U	
	PFTeDA	376-06-7	P240725018	ND	0.241	0.632			U	
	PFHxDA	67905-19-5	P240725018	ND	0.336	0.632			U	
	Sulfonates	PFBS	375-73-5	P240725018	2.86	0.336	0.632			
PFPeS		2706-91-4	P240725018	0.547	0.130	0.596			J	
PFHxS		355-46-4	P240725018	3.92	0.488	0.579				
PFHpS		375-92-8	P240725018	0.150	0.306	0.602			L	
PFOS		1763-23-1	P240725018	10.3	0.334	0.586				
PFNS		68259-12-1	P240725018	ND	0.196	0.609			U	
PFDS		335-77-3	P240725018	ND	0.332	0.609			U	
4:2 FTS		757124-72-4	P240725018	ND	0.0820	0.592			U	
8:2 FTS		39108-34-4	P240725018	0.0175	0.142	0.606			L	
10:2 FTS		120226-60-0	P240725018	ND	0.484	0.632			U	
Sulfonamidos	FBSA	30334-69-1	P240725018	0.449	0.300	0.632			J	
	N-EiFOSA	4151-50-2	P240725018	ND	0.391	0.632			U	
	N-EiFOSAA	2991-50-6	P240725018	ND	0.257	0.632			U	
	N-EiFOSE	1691-99-2	P240725018	ND	0.968	2.85			U	
	N-MeFOSA	31506-32-8	P240725018	ND	0.261	0.632			U	
	N-MeFOSAA	2355-31-9	P240725018	ND	0.178	0.632			U	
	N-MeFOSE	24448-09-7	P240725018	ND	0.601	2.85			U	
	PFOSA	754-91-6	P240725018	ND	0.0887	0.632			U	
	PFECAs	ADONA	919005-14-4	P240725018	ND	0.171	0.599			U
		EVE Acid	69087-46-3	P240725018	0.0000823	0.202	1.42			L
HFPO-DA		13252-13-6	P240725018	4.73	0.0670	0.632				
Hydro-EVE Acid		773804-62-9	P240725018	0.107	0.207	0.632			L	
NFDHA		151772-58-6	P240725018	ND	0.133	0.632			U	
PEPA		267239-61-2	P240725018	3.83	0.119	0.632				
PFECA-G		801212-59-9	P240725018	ND	0.0844	0.632			U	
PFMOAA		674-13-5	P240725018	17.3	0.320	0.632				
PFMOBA		863090-89-5	P240725018	ND	1.06	1.42			U	
PFMOPrA		377-73-1	P240725018	ND	0.225	0.632			U	
PFO2HxA		39492-88-1	P240725018	3.58	0.204	0.632				
PFO3OA		39492-89-2	P240725018	0.918	0.290	0.632				
PFO4DA		39492-90-5	P240725018	ND	0.500	3.16			U	
PFO5DA		39492-91-6	P240725018	ND	0.506	3.16			U	
PMPA		13140-29-9	P240725018	6.63	0.149	0.632				
R-EVE		2416366-22-6	P240725018	3.33	1.05	1.42				
PFESAs		11Cl-PF3OUds	763051-92-9	P240725018	ND	0.298	0.596			U
	9Cl-PF3ONS	756426-58-1	P240725018	ND	0.405	0.589			U	
	Hydrolyzed PSDA	2416366-19-1	P240725018	2.06	0.421	0.632				
	Nafion Byproduct 1 (PS Acid)	29311-67-9	P240725018	ND	0.338	0.632			U	
	Nafion Byproduct 2 (Hydro-PS Acid)	749836-20-2	P240725018	0.273	0.524	0.632			L	
	NVHOS	1132933-86-8	P240725018	0.254	0.0974	0.632			J	
	PFEESA	113507-82-7	P240725018	ND	0.190	0.632			U	
	R-PSDA	2416366-18-0	P240725018	2.94	2.79	2.79				
ES	R-PSDCA	2416366-21-5	P240725018	ND	0.267	0.632			U	
	MPFBA		P240725018				20-150%	75.5%		
	M5PFPeA		P240725018				20-150%	168%	Q	
	M3PFBS		P240725018				20-150%	241%	Q	
	M2-4:2 FTS		P240725018				20-150%	102%		
	M5PFHxA		P240725018				20-150%	75.5%		
	M3HFPO-DA		P240725018				20-150%	66.6%		
M4PFHpA		P240725018				20-150%	81.7%			
M3PFHxS		P240725018				20-150%	86.8%			

Enthalpy Analytical

Job No.: 0725-740-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	070325-S01	Prep Batch	EU118420
Sampling Site		Analyst	ext-magennaef
Enthalpy ID	0725-740-001-1A	Instrument	Pippin
Matrix	aqueous	Sample Vol mL	253.07
Sampling Date	2025-07-03 10:30	Extract Vol mL	0.4
Received Date	2025-07-07	Split Factor	N/A
Prep Date	2025-07-18 09:00	Method Code	EU-047-NPW
AnalysisDate	2025-07-24 20:32		
SampleType	Sample		
Bottle ID	A		

Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
M8PFOA		P240725018				20-150%	91.3%	
M9PFNA		P240725018				20-150%	91.5%	
M8PFOS		P240725018				20-150%	91.9%	
M2-8:2 FTS		P240725018				20-150%	87.3%	
M8FOSA-I		P240725018				20-150%	79.2%	
M6PFDA		P240725018				20-150%	84.2%	
d3-N-MeFOSAA		P240725018				20-150%	84.5%	
d5-N-EtFOSAA		P240725018				20-150%	88.3%	
M7PFUdA		P240725018				20-150%	86.9%	
MPPFD _o A		P240725018				20-150%	74.1%	
M2PFTeDA		P240725018				20-150%	42.9%	
d3-N-MeFOSA		P240725018				10-200%	8.45%	Q
d5-N-EtFOSA		P240725018				10-200%	6.36%	Q
d7-N-MeFOSE		P240725018				10-200%	46.3%	
d9-N-EtFOSE		P240725018				10-200%	40.6%	

Enthalpy Analytical

Job No.: 0725-740-1 PFAS by Isotope Dilution (non-potable water)
Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name 070325-S01
Sampling Site
Enthalpy ID 0725-740-001-2 Prep Batch EU118490
Matrix aqueous Analyst zoeardt
Sampling Date 2025-07-03 10:30 Instrument Pippin
Received Date 2025-07-07 Sample Vol mL 276.29
Prep Date 2025-07-31 09:30 Extract Vol mL 0.4
AnalysisDate 2025-08-01 21:21 Split Factor N/A
SampleType Sample Method Code EU-047-NPW
Bottle ID B

	Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Sulfonates	6:2 FTS	27619-97-2	P010825017	0.0432	0.273	0.552			L
ES	M2-6:2 FTS		P010825017				20-150%	55.7%	

Enthalpy Analytical

Job No.: 0725-740-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	070325-E01		
Sampling Site			
Enthalpy ID	0725-740-002-1	Prep Batch	EU118352
Matrix	aqueous	Analyst	jogres
Sampling Date	2025-07-03 10:30	Instrument	Bumblebee
Received Date	2025-07-07	Sample Vol mL	0.1
Prep Date	2025-07-10 16:14	Extract Vol mL	0.2
AnalysisDate	2025-07-10 18:35	Split Factor	N/A
SampleType	Sample	Method Code	EU-047-NPW
Bottle ID	A		

	Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFPrA	422-64-0	8100725-07101835	ND	700	1530			U
ES	13C3-PFPrA		8100725-07101835				20-150%	183%	Q

Enthalpy Analytical

Job No.: 0725-740-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	070325-E01	Prep Batch	EU118420
Sampling Site		Analyst	ext-magennaef
Enthalpy ID	0725-740-002-1A	Instrument	Pippin
Matrix	aqueous	Sample Vol mL	219.39
Sampling Date	2025-07-03 10:30	Extract Vol mL	0.4
Received Date	2025-07-07	Split Factor	N/A
Prep Date	2025-07-18 09:00	Method Code	EU-047-NPW
AnalysisDate	2025-07-24 20:54		
SampleType	Sample		
Bottle ID	A		

	Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags	
Acids	PFBA	375-22-4	P240725019	9.21	0.289	0.729				
	PFPeA	2706-90-3	P240725019	9.82	0.209	0.729				
	PFHxA	307-24-4	P240725019	89.4	0.244	0.729				
	PFFHpA	375-85-9	P240725019	5.85	0.255	0.729				
	PFOA	335-67-1	P240725019	7.08	0.167	0.729				
	PFNA	375-95-1	P240725019	1.09	0.165	0.729				
	PFDA	335-76-2	P240725019	0.510	0.209	0.729			J	
	PFUnDA	2058-94-8	P240725019	0.0122	0.165	0.729			L	
	PFDODA	307-55-1	P240725019	ND	0.296	0.729			U	
	PFTTrDA	72629-94-8	P240725019	ND	0.242	0.729			U	
	PFTeDA	376-06-7	P240725019	ND	0.278	0.729			U	
	PFFHxDA	67905-19-5	P240725019	ND	0.387	0.729			U	
	Sulfonates	PFBS	375-73-5	P240725019	3.31	0.387	0.729			
PFPeS		2706-91-4	P240725019	ND	0.150	0.687			U	
PFFHxS		355-46-4	P240725019	4.87	0.563	0.668				
PFFHpS		375-92-8	P240725019	0.176	0.353	0.695			L	
PFOS		1763-23-1	P240725019	20.0	0.385	0.676				
PFNS		68259-12-1	P240725019	ND	0.226	0.702			U	
PFDS		335-77-3	P240725019	ND	0.383	0.702			U	
4:2 FTS		757124-72-4	P240725019	3.72	0.0946	0.683				
8:2 FTS		39108-34-4	P240725019	0.818	0.163	0.699				
10:2 FTS		120226-60-0	P240725019	0.125	0.558	0.729				
Sulfonamidos	FBSA	30334-69-1	P240725019	0.379	0.346	0.729			J	
	N-EiFOSA	4151-50-2	P240725019	ND	0.451	0.729			U	
	N-EiFOSAA	2991-50-6	P240725019	ND	0.296	0.729			U	
	N-EiFOSE	1691-99-2	P240725019	ND	1.12	3.28			U	
	N-MeFOSA	31506-32-8	P240725019	ND	0.301	0.729			U	
	N-MeFOSAA	2355-31-9	P240725019	ND	0.205	0.729			U	
	N-MeFOSE	24448-09-7	P240725019	ND	0.693	3.28			U	
	PFOSA	754-91-6	P240725019	ND	0.102	0.729			U	
	PFECAs	ADONA	919005-14-4	P240725019	ND	0.198	0.691			U
		EVE Acid	69087-46-3	P240725019	0.00112	0.232	1.64			L
HFPO-DA		13252-13-6	P240725019	5.95	0.0773	0.729				
Hydro-EVE Acid		773804-62-9	P240725019	0.492	0.239	0.729			J	
NFDHA		151772-58-6	P240725019	ND	0.153	0.729			U	
PEPA		267239-61-2	P240725019	3.99	0.137	0.729				
PFECA-G		801212-59-9	P240725019	ND	0.0973	0.729			U	
PFMOAA		674-13-5	P240725019	10.0	0.369	0.729				
PFMOBA		863090-89-5	P240725019	ND	1.22	1.64			U	
PFMOPrA		377-73-1	P240725019	ND	0.260	0.729			U	
PFO2HxA		39492-88-1	P240725019	3.14	0.235	0.729				
PFO3OA		39492-89-2	P240725019	0.940	0.335	0.729				
PFO4DA		39492-90-5	P240725019	ND	0.577	3.65			U	
PFO5DA		39492-91-6	P240725019	ND	0.583	3.65			U	
PMPA		13140-29-9	P240725019	8.58	0.172	0.729				
R-EVE		2416366-22-6	P240725019	11.7	1.21	1.64				
PFESAs		11Cl-PF3OUds	763051-92-9	P240725019	ND	0.344	0.687			U
		9Cl-PF3ONS	756426-58-1	P240725019	ND	0.467	0.679			U
		Hydrolyzed PSDA	2416366-19-1	P240725019	9.24	0.485	0.729			
	Nafion Byproduct 1 (PS Acid)	29311-67-9	P240725019	ND	0.390	0.729			U	
	Nafion Byproduct 2 (Hydro-PS Acid)	749836-20-2	P240725019	0.603	0.604	0.729			L	
	NVHOS	1132933-86-8	P240725019	1.15	0.112	0.729				
	PFEESA	113507-82-7	P240725019	ND	0.219	0.729			U	
	R-PSDA	2416366-18-0	P240725019	11.1	3.21	3.21				
ES	R-PSDCA	2416366-21-5	P240725019	0.0288	0.308	0.729			L	
	MPFBA		P240725019				20-150%	73.2%		
	M5PFPeA		P240725019				20-150%	163%	Q	
	M3PFBS		P240725019				20-150%	243%	Q	
	M2-4:2 FTS		P240725019				20-150%	132%		
	M5PFFHxA		P240725019				20-150%	277%	Q	
	M3HFPO-DA		P240725019				20-150%	125%		
	M4PFFHpA		P240725019				20-150%	58.3%	Ac	
M3PFFHxS		P240725019				20-150%	117%			

Enthalpy Analytical

Job No.: 0725-740-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	070325-E01	Prep Batch	EU118420
Sampling Site		Analyst	ext-magennaef
Enthalpy ID	0725-740-002-1A	Instrument	Pippin
Matrix	aqueous	Sample Vol mL	219.39
Sampling Date	2025-07-03 10:30	Extract Vol mL	0.4
Received Date	2025-07-07	Split Factor	N/A
Prep Date	2025-07-18 09:00	Method Code	EU-047-NPW
AnalysisDate	2025-07-24 20:54		
SampleType	Sample		
Bottle ID	A		

Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
M8PFOA		P240725019				20-150%	96.1%	Q
M9PFNA		P240725019				20-150%	266%	
M8PFOS		P240725019				20-150%	90.1%	
M2-8:2 FTS		P240725019				20-150%	48.6%	
M8FOSA-I		P240725019				20-150%	108%	
M6PFDA		P240725019				20-150%	83.2%	
d3-N-MeFOSAA		P240725019				20-150%	46.8%	
d5-N-EtFOSAA		P240725019				20-150%	99.4%	
M7PFUdA		P240725019				20-150%	83.1%	
MPPFD _o A		P240725019				20-150%	61.6%	
M2PFT _e DA		P240725019				20-150%	27.5%	
d3-N-MeFOSA		P240725019				10-200%	49.7%	
d5-N-EtFOSA		P240725019				10-200%	38.0%	
d7-N-MeFOSE		P240725019				10-200%	59.9%	
d9-N-EtFOSE		P240725019				10-200%	44.8%	

Enthalpy Analytical

Job No.: 0725-740-1 PFAS by Isotope Dilution (non-potable water)
Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name 070325-E01
Sampling Site
Enthalpy ID 0725-740-002-2 Prep Batch EU118490
Matrix aqueous Analyst zoeardt
Sampling Date 2025-07-03 10:30 Instrument Pippin
Received Date 2025-07-07 Sample Vol mL 272.74
Prep Date 2025-07-31 09:30 Extract Vol mL 0.4
AnalysisDate 2025-08-01 21:44 Split Factor N/A
SampleType Sample Method Code EU-047-NPW
Bottle ID B

	Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Sulfonates	6:2 FTS	27619-97-2	P010825018	0.0837	0.277	0.559			L
ES	M2-6:2 FTS		P010825018				20-150%	61.1%	

QC Data

Enthalpy Analytical

Job No.: 0725-740-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	MB_118352_PFAS	Prep Batch	EU118352
Sampling Site		Analyst	jogres
Enthalpy ID	MB_118352_PFAS	Instrument	Bumblebee
Matrix	aqueous	Sample Vol mL	0.1
Sampling Date		Extract Vol mL	0.2
Received Date		Split Factor	N/A
Prep Date	2025-07-10 16:14	Method Code	EU-047-NPW
AnalysisDate	2025-07-10 17:37		
SampleType	Blank		
Bottle ID	-		

	Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFPrA	422-64-0	8100725-07101737	ND	700	1530			U
ES	13C3-PFPrA		8100725-07101737				20-150%	169%	Q

Enthalpy Analytical

Job No.: 0725-740-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	MB_118420_PFAS	Prep Batch	EU118420
Sampling Site		Analyst	ext-magennaef
Enthalpy ID	MB_118420_PFAS	Instrument	Pippin
Matrix	aqueous	Sample Vol mL	250
Sampling Date		Extract Vol mL	0.4
Received Date		Split Factor	N/A
Prep Date	2025-07-18 09:00	Method Code	EU-047-NPW
AnalysisDate	2025-07-24 18:15		
SampleType	Blank		
Bottle ID	-		

	Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags	
Acids	PFBA	375-22-4	P240725012	ND	0.254	0.640			U	
	PFPeA	2706-90-3	P240725012	ND	0.183	0.640			U	
	PFHxA	307-24-4	P240725012	ND	0.214	0.640			U	
	PFFHpA	375-85-9	P240725012	ND	0.224	0.640			U	
	PFOA	335-67-1	P240725012	ND	0.146	0.640			U	
	PFNA	375-95-1	P240725012	ND	0.145	0.640			U	
	PFDA	335-76-2	P240725012	ND	0.183	0.640			U	
	PFUnDA	2058-94-8	P240725012	ND	0.145	0.640			U	
	PFDaDA	307-55-1	P240725012	ND	0.260	0.640			U	
	PFTrDA	72629-94-8	P240725012	ND	0.212	0.640			U	
	PFTeDA	376-06-7	P240725012	ND	0.244	0.640			U	
	PFFHxDA	67905-19-5	P240725012	ND	0.340	0.640			U	
	Sulfonates	PFBS	375-73-5	P240725012	ND	0.340	0.640			U
		PFPeS	2706-91-4	P240725012	ND	0.131	0.603			U
PFFHxS		355-46-4	P240725012	ND	0.494	0.586			U	
PFFHpS		375-92-8	P240725012	0.00158	0.310	0.610			L	
PFOS		1763-23-1	P240725012	ND	0.338	0.593			U	
PFNS		68259-12-1	P240725012	ND	0.199	0.616			U	
PFDS		335-77-3	P240725012	ND	0.336	0.616			U	
4:2 FTS		757124-72-4	P240725012	ND	0.0830	0.600			U	
8:2 FTS		39108-34-4	P240725012	0.0741	0.143	0.613			L	
10:2 FTS		120226-60-0	P240725012	ND	0.490	0.640			U	
Sulfonamidos	FBSA	30334-69-1	P240725012	ND	0.304	0.640			U	
	N-EiFOSA	4151-50-2	P240725012	ND	0.396	0.640			U	
	N-EiFOSAA	2991-50-6	P240725012	ND	0.260	0.640			U	
	N-EiFOSE	1691-99-2	P240725012	ND	0.980	2.88			U	
	N-MeFOSA	31506-32-8	P240725012	ND	0.264	0.640			U	
	N-MeFOSAA	2355-31-9	P240725012	ND	0.180	0.640			U	
	N-MeFOSE	24448-09-7	P240725012	ND	0.608	2.88			U	
	PFOSA	754-91-6	P240725012	ND	0.0898	0.640			U	
	PFECAs	ADONA	919005-14-4	P240725012	ND	0.173	0.606			U
		EVE Acid	69087-46-3	P240725012	0.000511	0.204	1.44			L
HFPO-DA		13252-13-6	P240725012	ND	0.0678	0.640			U	
Hydro-EVE Acid		773804-62-9	P240725012	ND	0.210	0.640			U	
NFDHA		151772-58-6	P240725012	ND	0.135	0.640			U	
PEPA		267239-61-2	P240725012	ND	0.120	0.640			U	
PFECA-G		801212-59-9	P240725012	ND	0.0854	0.640			U	
PFMOAA		674-13-5	P240725012	ND	0.324	0.640			U	
PfMOBA		863090-89-5	P240725012	ND	1.07	1.44			U	
PfMOPrA		377-73-1	P240725012	ND	0.228	0.640			U	
PFO2HxA		39492-88-1	P240725012	ND	0.206	0.640			U	
PFO3OA		39492-89-2	P240725012	ND	0.294	0.640			U	
PFO4DA		39492-90-5	P240725012	ND	0.506	3.20			U	
PFO5DA		39492-91-6	P240725012	ND	0.512	3.20			U	
PMPA		13140-29-9	P240725012	ND	0.151	0.640			U	
R-EVE		2416366-22-6	P240725012	ND	1.06	1.44			U	
PFESAs	11Cl-PF3OUds	763051-92-9	P240725012	ND	0.302	0.603			U	
	9Cl-PF3ONS	756426-58-1	P240725012	ND	0.410	0.596			U	
	Hydrolyzed PSDA	2416366-19-1	P240725012	ND	0.426	0.640			U	
	Nafion Byproduct 1 (PS Acid)	29311-67-9	P240725012	ND	0.342	0.640			U	
	Nafion Byproduct 2 (Hydro-PS Acid)	749836-20-2	P240725012	ND	0.530	0.640			U	
	NVHOS	1132933-86-8	P240725012	ND	0.0986	0.640			U	
	PFEESA	113507-82-7	P240725012	ND	0.192	0.640			U	
	R-PSDA	2416366-18-0	P240725012	ND	2.82	2.82			U	
ES	R-PSDCA	2416366-21-5	P240725012	ND	0.270	0.640			U	
	MPFBA		P240725012				20-150%	93.3%		
	M5PFPeA		P240725012				20-150%	96.4%		
	M3PFBS		P240725012				20-150%	85.4%		
	M2-4:2 FTS		P240725012				20-150%	119%		
	M5PFFHxA		P240725012				20-150%	95.6%		
	M3HFPO-DA		P240725012				20-150%	84.1%		
M4PFFHpA		P240725012				20-150%	89.7%			
M3PFFHxS		P240725012				20-150%	99.7%			

Enthalpy Analytical

Job No.: 0725-740-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	MB_118420_PFAS	Prep Batch	EU118420
Sampling Site		Analyst	ext-magennaef
Enthalpy ID	MB_118420_PFAS	Instrument	Pippin
Matrix	aqueous	Sample Vol mL	250
Sampling Date		Extract Vol mL	0.4
Received Date		Split Factor	N/A
Prep Date	2025-07-18 09:00	Method Code	EU-047-NPW
AnalysisDate	2025-07-24 18:15		
SampleType	Blank		
Bottle ID	-		

Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
M8PFOA		P240725012				20-150%	95.0%	
M9PFNA		P240725012				20-150%	90.2%	
M8PFOS		P240725012				20-150%	103%	
M2-8:2 FTS		P240725012				20-150%	95.7%	
M8FOSA-I		P240725012				20-150%	86.2%	
M6PFDA		P240725012				20-150%	92.5%	
d3-N-MeFOSAA		P240725012				20-150%	97.5%	
d5-N-EtFOSAA		P240725012				20-150%	97.7%	
M7PFUDa		P240725012				20-150%	98.5%	
MPPFDaA		P240725012				20-150%	91.1%	
M2PFTeDA		P240725012				20-150%	77.9%	
d3-N-MeFOSA		P240725012				10-200%	10.7%	
d5-N-EtFOSA		P240725012				10-200%	10.6%	
d7-N-MeFOSE		P240725012				10-200%	70.4%	
d9-N-EtFOSE		P240725012				10-200%	73.2%	

Enthalpy Analytical

Job No.: 0725-740-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	MB_118490_PFAS	Prep Batch	EU118490
Sampling Site		Analyst	zoeardt
Enthalpy ID	MB_118490_PFAS	Instrument	Pippin
Matrix	aqueous	Sample Vol mL	250
Sampling Date		Extract Vol mL	0.4
Received Date		Split Factor	N/A
Prep Date	2025-07-31 09:30	Method Code	EU-047-NPW
AnalysisDate	2025-08-01 16:03		
SampleType	Blank		
Bottle ID	-		

	Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Sulfonates	6:2 FTS	27619-97-2	P010825003	ND	0.302	0.610			U
ES	M2-6:2 FTS		P010825003				20-150%	51.8%	

Enthalpy Analytical

Job No.: 0725-740-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	OPR_118352_PFAS	Prep Batch	EU118352
Sampling Site		Analyst	jogres
Enthalpy ID	OPR_118352_PFAS	Instrument	Bumblebee
Matrix	aqueous	Sample Vol mL	0.1
Sampling Date		Extract Vol mL	0.2
Received Date		Split Factor	N/A
Prep Date	2025-07-10 16:14	Method Code	EU-047-NPW
AnalysisDate	2025-07-10 17:49		
SampleType	Control		
Bottle ID	-		

	Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFPrA	422-64-0	8100725-07101749	28600	700	1530	40-150%	143%	
ES	13C3-PFPrA		8100725-07101749				20-150%	190%	Q

Enthalpy Analytical

Job No.: 0725-740-1 PFAS by Isotope Dilution (non-potable water)

Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Enthalpy ID	OPR_118420_PFAS	Prep Batch	EU118420	Sample Vol (mL)	250
Sample Name	OPR_118420_PFAS	Prep Date	2025-07-18 09:00	Extract Vol (mL)	0.4
Matrix	aqueous	Analysis Date	2025-07-24 18:38	Split Factor	N/A
Sampling Date		Analyst	ext-magennaef	Method Code	EU-047-NPW
Received Date		Instrument	Pippin	Sample Type	Control
		Bottle ID	-		

	Compound	CAS	InjFileName	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags	
Acids	PFBA	375-22-4	P240725013	22.9	0.254	0.640	47.9-144%	114%		
	PFPeA	2706-90-3	P240725013	22.5	0.183	0.640	41.7-159%	113%		
	PFHxA	307-24-4	P240725013	22.3	0.214	0.640	43.2-154%	112%		
	PFHpA	375-85-9	P240725013	23.1	0.224	0.640	42.1-155%	116%		
	PFOA	335-67-1	P240725013	21.6	0.146	0.640	51.1-148%	108%		
	PFNA	375-95-1	P240725013	23.4	0.145	0.640	51.6-153%	117%		
	PFDA	335-76-2	P240725013	24.0	0.183	0.640	44.5-156%	120%		
	PFUnDA	2058-94-8	P240725013	22.1	0.145	0.640	40.3-156%	110%		
	PFDoDA	307-55-1	P240725013	23.9	0.260	0.640	40.4-158%	119%		
	PFTrDA	72629-94-8	P240725013	24.5	0.212	0.640	42.2-201%	123%		
	PFTeDA	376-06-7	P240725013	23.0	0.244	0.640	43-162%	115%		
	Sulfonates	PFBS	375-73-5	P240725013	19.5	0.340	0.640	42.7-155%	110%	
		PFPeS	2706-91-4	P240725013	19.2	0.131	0.603	40.3-152%	102%	
PFHxS		355-46-4	P240725013	21.1	0.494	0.586	45-148%	115%		
PFHpS		375-92-8	P240725013	20.9	0.310	0.610	39.8-166%	110%		
PFOS		1763-23-1	P240725013	19.5	0.338	0.593	59.2-132%	105%		
PFNS		68259-12-1	P240725013	20.4	0.199	0.616	38.1-153%	106%		
PFDS		335-77-3	P240725013	19.8	0.336	0.616	28.6-148%	103%		
4:2 FTS		757124-72-4	P240725013	22.1	0.0830	0.600	41.5-157%	118%		
8:2 FTS		39108-34-4	P240725013	22.5	0.143	0.613	39.4-166%	117%		
Sulfonamidos		N-EtFOSA	4151-50-2	P240725013	19.7	0.396	0.640	26.7-172%	98.5%	
	N-EtFOSAA	2991-50-6	P240725013	20.8	0.260	0.640	42.8-156%	104%		
	N-EtFOSE	1691-99-2	P240725013	84.8	0.980	2.88	38.9-161%	94.2%		
	N-MeFOSA	31506-32-8	P240725013	21.0	0.264	0.640	26.4-183%	105%		
	N-MeFOSAA	2355-31-9	P240725013	21.7	0.180	0.640	42-155%	108%		
	N-MeFOSE	24448-09-7	P240725013	91.8	0.608	2.88	37.6-155%	102%		
	PFOSA	754-91-6	P240725013	24.0	0.0898	0.640	39.1-158%	120%		
PFECAs	ADONA	919005-14-4	P240725013	20.5	0.173	0.606	32.2-151%	102%		
	HFPO-DA	13252-13-6	P240725013	22.9	0.0678	0.640	61.8-131%	114%		
PFESAs	11Cl-PF3OUdS	763051-92-9	P240725013	18.4	0.302	0.603	21.8-141%	91.8%		
	9Cl-PF3ONS	756426-58-1	P240725013	20.1	0.410	0.596	37.6-146%	101%		
ES	MPFBA		P240725013				20-150%	87.4%		
	M5PFPeA		P240725013				20-150%	88.4%		
	M3PFBS		P240725013				20-150%	83.3%		
	M2-4:2 FTS		P240725013				20-150%	107%		
	M5PFHxA		P240725013				20-150%	92.0%		
	M3HFPO-DA		P240725013				20-150%	84.3%		
	M4PFHpA		P240725013				20-150%	87.1%		
	M3PFHxS		P240725013				20-150%	90.8%		
	M8PFOA		P240725013				20-150%	93.1%		
	M9PFNA		P240725013				20-150%	88.6%		
	M8PFOS		P240725013				20-150%	93.8%		
	M2-8:2 FTS		P240725013				20-150%	89.7%		
	M8FOSA-I		P240725013				20-150%	76.9%		
	M6PFDA		P240725013				20-150%	86.3%		
	d3-N-MeFOSAA		P240725013				20-150%	88.9%		
	d5-N-EtFOSAA		P240725013				20-150%	92.3%		
	M7PFUdA		P240725013				20-150%	90.1%		
	MPFDoA		P240725013				20-150%	79.1%		
	M2PFTeDA		P240725013				20-150%	67.2%		
	d3-N-MeFOSA		P240725013				10-200%	3.53%	Q	
d5-N-EtFOSA		P240725013				10-200%	3.30%	Q		
d7-N-MeFOSE		P240725013				10-200%	51.2%			
d9-N-EtFOSE		P240725013				10-200%	54.4%			

Enthalpy Analytical

Job No.: 0725-740-1 PFAS by Isotope Dilution (non-potable water)
 Brunswick County Public Utilities - NC NORTHWEST WATER PLANT LELAND N.C.

Details

Sample Name	OPR_118490_PFAS		
Sampling Site			
Enthalpy ID	OPR_118490_PFAS	Prep Batch	EU118490
Matrix	aqueous	Analyst	zoeardt
Sampling Date		Instrument	Pippin
Received Date		Sample Vol mL	250
Prep Date	2025-07-31 09:30	Extract Vol mL	0.4
AnalysisDate	2025-08-01 16:26	Split Factor	N/A
SampleType	Control	Method Code	EU-047-NPW
Bottle ID	-		

	Compound	CAS	Injection File Name	Sample Concentration ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Sulfonates	6:2 FTS	27619-97-2	P010825004	20.2	0.302	0.610	44.5-160%	106%	
ES	M2-6:2 FTS		P010825004				20-150%	69.6%	

Sample Custody

0725-740



Chain of Custody Record

Enthalpy Ultratrace Job#: _____ COC Page 1 of 1

Special Handling:

- Standard Turn Around Time
- Rush Turn Around Time -- Date Needed _____
- All Fast TATs Subject to Approval by Enthalpy Analytical, Inc.
- All Samples Disposed of After 6 months Unless Otherwise Instructed.

Enthalpy Analytical-Wilmington, NC has added enhancements to standard methods to improve accuracy, precision and permit an assessment of laboratory performance in the context of your specific data needs. For more information email Cindy.James@enthalpy.com.

Client Name: BRUNSWICK COUNTY UTILITIES
 Project Manager: GLENN WALKER
 Report To: SAME

Project Number: _____
 Site Name: NORTHWEST WATER PLANT
 Location: LELAND N.C.

PO#: _____
 Telephone#: _____
 Email: _____

This Chain of Custody is applicable to Non-Air samples. Standard TAT differ per analysis and are provided by request.

Client Special Instructions:

Matrix: GW-Groundwater, WW-Wastewater, NW-Non-Potable Water, DW-Drinking Water, S-Soil, SL-Sludge, BT-Biological Tissue, O-Other

Type: G=Grab C=Composite Q=Quality Control

Sample ID	Date	Time	Sample Volume	Type	Matrix	Sample Containers				Analyses						Notes			
						# of Bottles	# of Jars	# of Bags	# Other	Method 1613	Method 8290	Method 1668A/B/C PCE	PFAS by LC/MS/MS	PAHs by HRGC/HRMS	Sample on Hold		Method 23	ALL PFAS	
070325-S01	7/3/2025	10:30 AM	250 ml	G	NW	2											X	Please Add PFPA and	
070325-E01	7/3/2025	10:30 AM	250 ml	G	DW	2												X	PFHpA To The Testing.
																			Mark Hager Knows About
																			This If you Have Questions

Relinquished By	Date	Received By	Date	Time	Sample Temperature Upon Receipt
PHIL MCCULLOCH	7/7/2025	<i>[Signature]</i>	7/7/25	14:20	<input checked="" type="checkbox"/> Iced <input type="checkbox"/> Ambient °C <u>1.1</u>
			TE S.S. 7/7/25		<input type="checkbox"/> Iced <input type="checkbox"/> Ambient °C _____
					<input type="checkbox"/> Iced <input type="checkbox"/> Ambient °C _____

JOB ID:

[]

Date / Time:

7/7/25 14:20

Initials:

S.S.

OR

Client:

Brunswick

Cooler

1

of

1

Temp °C:

1.1

Thermometer ID:

T16

Received via

FedEx

UPS

DHL

USPS

Courier

Other

Check one

On ice:

Melted ice:

Ambient:

Check one

in a Box:

in a Cooler:

Cooler in Box:

Yes

No

Cooler seals:

Sample seals:

Good condition:

Comment:

* TE S.S. 7/7/25

Cooler

[]

of

[]

Temp °C:

[]

Thermometer ID:

[]

Received via

FedEx

UPS

DHL

USPS

Courier

Other

Check one

On ice:

Melted ice:

Ambient:

Check one

in a Box:

in a Cooler:

Cooler in Box:

Yes

No

Cooler seals:

Sample seals:

Good condition:

Comment:

[]

Cooler

[]

of

[]

Temp °C:

[]

Thermometer ID:

[]

Received via

FedEx

UPS

DHL

USPS

Courier

Other

Check one

On ice:

Melted ice:

Ambient:

Check one

in a Box:

in a Cooler:

Cooler in Box:

Yes

No

Cooler seals:

Sample seals:

Good condition:

Comment:

[]